

Samsung
Electronics
EHS

**Tank Integrated
Hydro Unit**

Design & Installation



Modification history

| Date | Ver. | Modifier | Modified detail | Remarks |
|-----------|------|-------------|--|---------|
| 22 Apr 16 | 0.0 | Sungtae Kim | Made the original version of installation training materials | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Content

S

- ◆ **Process and General installation guide**
- ◆ **Tank Integrated Hydro unit**
- ◆ **Split outdoor unit**
- ◆ **Mono outdoor unit**
- ◆ **External wiring and set up with Hydro unit**
- ◆ **Switches & Keys' functions**
- ◆ **Field Setting Value**

Proces

S

- Before start
- What is EHS
- Nomenclature
- Preparation of installation
- General guide of pipe drawing
- Installation tip
- Required tool



Before start

- Things what should be checked before installation
 - ▶ Read **Installation Manual** carefully to guarantee the proper installation
 - ▶ Every information which is related to proper installation is in Installation Manual and **Technical Data Book**
 - ▶ Proper installation will improve the **reliability & performance** of the system
 - ▶ **Keep safety** at 1st place while working at site
 - ▶ Right tool, enough material & well-trained workers should be on site

When you have any technical question or support is required please access
BTSP.

<https://btsp.samsunggsbn.com>


What is EHS

What is EHS


Eco Heating System

- ✓ Heating or Cooling can be used with Hot or Cold Water
- ✓ High Efficiency than conventional boiler
- ✓ Inverter compressor & R-32 refrigerant
- ✓ 3Type in EHS
 - Split : R-32 Outdoor Unit + Hydro Unit (Including PHE)
 - Mono : R-32 Outdoor Unit (Including PHE)
 - TDM : R-32 Outdoor Unit+Hydro Unit + Aircon Indoor Unit


Split



Mono



TDM




What is EHS

■ System Types – Tank Integrated Split


- Both water heating and hot water supply
- Reversible (water cooling enable)
- Outdoor Unit + Hydro Unit + DHW Tank
- Hybrid Energy Source : Solar Collector (field supply)

Back-up Boiler (field supply)



What is EHS

- System Types – Tank Integrated Mono
 - Both water heating and hot water supply
 - Reversible (water cooling enable)
 - Mono Unit + DHW Tank
 - Hybrid Energy Source : Solar Collector (field supply)



Nomenclature

Model Name

AE

(1)

200

(2)

R

(3)

N

(4)

W

(5)

S

(6)

E

(7)

G

(8)

/

EU

(Buyer)

(1) Classification

| | |
|----|-----|
| AE | EHS |
|----|-----|

(5) Feature 1
(Indoor Unit)

| | |
|---|-------------------------------|
| W | Tank Integrated Hydro Unit |
|---|-------------------------------|

(6) Feature 2
(Indoor Unit)

| | |
|---|-------|
| S | Split |
| M | Mono |

(7) Voltage

| | |
|---|-----------------------|
| E | E(220~240V, 50Hz) |
| G | G(380~415V, 50Hz, 3Φ) |

(2) Capacity (3Digit)

| | |
|-----|--------|
| HP | x 1/10 |
| BTU | x 1000 |

(5) Feature 1
(Outdoor Unit)

| | |
|---|--------------|
| E | Single Split |
| Y | Mono |

(6) Feature 2
(Outdoor Unit)

| | |
|---|-------|
| D | Basic |
|---|-------|

(8) Mode

| | | |
|---|-----------|------|
| G | Heat Pump | R-32 |
|---|-----------|------|

(3) Year

| | |
|---|------|
| R | 2019 |
|---|------|

(4) Type

| | |
|---|--------------|
| N | Indoor unit |
| X | Outdoor Unit |



Preparation of installation

■ Precautions

IMPORTANT: When installing the unit, always remember to connect first the refrigerant tubes, then the electrical lines. Always disassemble the electric lines before the refrigerant tubes.

- ▶ Upon receipt, inspect the product to verify that it has not been damaged during transport. If the product appears damaged, DO NOT INSTALL it and immediately report the damage to the carrier or retailer (if the installer or the authorized technician has collected the material from the retailer.)
- ▶ After completing the installation, always carry out a functional test and provide the instructions on how to operate the air to water heat pump to the user.
- ▶ Do not use the air to water heat pump in environments with hazardous substances or close to equipment that release free flames to avoid the occurrence of fires, explosions or injuries.
- ▶ While in installation or relocation of the product, do not mix the refrigerant with other gases including air or unspecified refrigerant. Failure to do so may cause pressure increase to result in rupture or injury.
- ▶ Do not cut or burn the refrigerant container or pipings.
- ▶ Use clean parts such as manifold gauge, vacuum pump, and charging hose for the refrigerant.
- ▶ Installation must be carried out by qualified personnel for handling the refrigerant. Additionally, reference the regulations and laws.
- ▶ Be careful not to let foreign substances (lubricating oil, refrigerant other than R-32, water, etc.) enter the pipings.
- ▶ When mechanical ventilation is required, ventilation openings shall be kept clear of obstruction.
- ▶ For disposal of the product, follow the local laws and regulations.
- ▶ Do not work in a confined place.
- ▶ The work area shall be blocked.
- ▶ The refrigerant pipings shall be installed in the position where there are no substances that may result in corrosion.
- ▶ The following checks shall be performed for installation:
 - The ventilation devices and outlets are operating normally and are not obstructed.
 - Markings and signs on the equipment shall be visible and legible.



Preparation of installation

■ Precautions

- ▶ Upon leakage of the refrigerant, ventilate the room. When the leaked refrigerant is exposed to flame, it may cause generation of toxic gases.
- ▶ Make sure that the work area is safe from flammable substances.
- ▶ To purge air in the refrigerant, be sure to use a vacuum pump.
- ▶ Note that the refrigerant has no odour.
- ▶ The units are not explosion proof so they must be installed with no risk of explosion.
- ▶ This product contains fluorinated gases that contribute to global greenhouse effect. Accordingly, do not vent gases into the atmosphere.
- ▶ For installation with handling the refrigerant(R-32), use dedicated tools and piping materials.
- ▶ Servicing and installation shall be performed as recommended by the manufacturer. In case other skilled persons are joined for servicing, it shall be carried out under supervision of the person who is competent in handling flammable refrigerants.
- ▶ For servicing the units containing flammable refrigerants, safety checks are required to minimise the risk of ignition.
- ▶ Servicing shall be performed following the controlled procedure to minimize the risk of flammable refrigerant or gases.
- ▶ Do not install where there is a risk of combustible gas leakage.
- ▶ Do not place heat sources.
- ▶ Be cautious not to generate a spark as follows: Do not remove the fuses with power on.
Do not disconnect the power plug from the wall outlet with power on.
It is recommended to locate the outlet in a high position. Place the cords so that they are not tangled.
- ▶ If the indoor unit is not R-32 compatible, an error signal appears and the unit will not operate.
- ▶ After installation, check for leakage. Toxic gas may be generated and if it comes into contact with an ignition source such as fan heater, stove, and cooker. cylinders, make sure that only the refrigerant recovery cylinders are used.
- ▶ Never directly touch any accidental leaking refrigerant.
- ▶ This could result in severe wounds caused by frostbite.

Preparation of installation

■ Indoor unit / Outdoor unit compatibility

| | | | | Indoor Unit | | | | | | | | | |
|--------------|--------------|------------|-------------|-------------------------|-------------|-------------|------------------------|-------------|-----------------|----------------------|----------------------|--------------------|---|
| | | | | Tank integrated (Split) | | | Tank integrated (Mono) | | | Wall-mounted type | | Mono | |
| Type | Power Source | Model Name | Capa. | 200L(1Φ) | 260L(1Φ) | 260L(3Φ) | 200L(1Φ) | 260L(1Φ) | 260L(3Φ) | Split(1Φ) | Split(3Φ) | | |
| | | | | AE200RNWSEG | AE260RNWSEG | AE260RNWSGG | AE200RNWMEG | AE260RNWMEG | AE260RNWMG G | AE090RNYDEG (W43) | AE090RNYDEG (W43) | MIM-E03CN (W31) | |
| Outdoor unit | Split | 1Φ | AE040RXEDEG | 4kW | ● | ● | | | | | ● | | |
| | | | AE060RXEDEG | 6kW | ● | ● | | | | | ● | | |
| | | | AE090RXEDEG | 9kW | ● | ● | | | | | ● | | |
| | | 3Φ | AE090RXEDGG | 9kW | | | ● | | | | ● | ● | |
| | Mono | 1Φ | AE050RXYDEG | 5kW | | | | ● | | | | | ● |
| | | | AE080RXYDEG | 8kW | | | | ● | ● | | | | ● |
| | | | AE120RXYDEG | 12kW | | | | ● | ● | | | | ● |
| | | | AE160RXYDEG | 16kW | | | | ● | ● | | | | ● |
| | | 3Φ | AE080RXYDGG | 8kW | | | | | | ● | | | ● |
| | | | AE120RXYDGG | 12kW | | | | | | ● | | | ● |
| AE160RXYDGG | 16kW | | | | | | | ● | | | ● | | |

Preparation of installation


■ Move the unit

▷ Moving the indoor unit with a fork lift

- elect the moving route in advance.
- Be sure that moving route is safe from weight of the indoor unit.


▷ Moving the outdoor unit with a fork lift

- Insert the fork into the wooden pallet at the bottom of the outdoor unit carefully.
Be careful that the fork does not damage the outdoor unit.
- A minimum of two people should lift the unit by the handles




▷ Moving the outdoor unit with a fork lift

- Insert the fork into the wooden pallet at the bottom of the outdoor unit carefully.
Be careful that the fork does not damage the outdoor unit.



▷ Moving the outdoor unit by wire rope


- Fasten the outdoor unit by two 8m or longer wire ropes as shown at the figure. To prevent from damage or scratches, insert a piece of cloth between the outdoor unit and rope, then move the unit.



* The appearance of the unit may be different from the picture depending on the model.

General guide of pipe drawing

■ Pipe limitation – 4/6/9 kW 1 fan Split outdoor unit



| Category | | Length | | Remark |
|------------------|------------|--------|-----|--------|
| | | 4/6kW | 9kW | |
| ODU to IDU | | 30m | 35m | ↔ |
| Level difference | H1 ODU-IDU | 15m | 15m | |
| | H2 ODU-IDU | 20m | 20m | |

※ Check installation manuals to find more information

Additional refrigerant charging

[SPLIT]

| Outdoor unit | Liquid Pipe [mm] | Gas Pipe [mm] | Factory charge [kg] |
|--------------|------------------|---------------|---------------------|
| AE040RXEDEG | ø6.35 | ø15.88 | 1.2 |
| AE060RXEDEG | ø6.35 | ø15.88 | 1.2 |
| AE090RXEDEG | ø6.35 | ø15.88 | 1.4 |
| AE090RXEDGG | ø6.35 | ø15.88 | 1.4 |

$$\text{Additional Charge[g]} = (L - 15) \times 20$$

Copper pipe


■ Copper pipe

- ✓ ASTM standard copper pipe
- ✓ Follow the minimum thickness & temper grade.
Otherwise pipe may be broken due to high pressure
- ✓ Use proper tool

| Pipe size mm(inch) | Minimum thickness(mm) | Temper grade |
|--------------------|-----------------------|---------------|
| Φ 6.35(1/4") | 0.7 | Annealed type |
| Φ 9.52(3/8") | 0.7 | |
| Φ12.70(1/2") | 0.8 | C1220T-O |
| Φ15.88(5/8") | 1.0 | |



*** Brazing required to keep pipe more than 1 month on site**



Nitrogen gas blowing


■ Nitrogen gas blowing

- To prevent buildup of non-condensable substances in the refrigerant pipes, nitrogen blowing must be used during brazing of copper connections
- Failure to use nitrogen while brazing will cause accumulation of oxides at the compressor, various strainers, and expansion valves impacting performance and causing premature failure

With Nitrogen




Without Nitrogen blowing





Ex) Filter clinginess

Nitrogen gas blowing

■ Nitrogen gas blowing



- ✓ Connect a nitrogen tank near the point that will be brazed
- ✓ Using a flow regulator, maintain 5.0ℓ/min [1.76 ft³/hr] of dry nitrogen
- ✓ If flow is too low, it will not effectively prevent oxide formation
- ✓ If flow is too high, it will be difficult to make a quality brazed connection
- ✓ Maintain flow after brazing is complete until pipe is no longer hot





Brazing


■ Brazing

- Make sure that there are no foreign materials and impurities inside the pipe.
- Use socket when need brazing for connecting pipes.


The stopper area of socket should be covered with welding material




(Expanding pipe brazing)



(Pipe brazing with socket)



(Flare brazing)



(Butt brazing)


Mounting

■ Mounting

1) Installing the hanger bolt(or others like ladder tray)

- $\Phi 12.7$ or less : 1.5m or less
- $\Phi 15.88$ or more : 2m or less

* If the distance is longer, pipe might be sagged by its weight




2) Insulating the pipe (Refer to Insulation work)

- Keep the tape or cap end of each side



3) Hanging the pipe

- Insert Insulation pad between pipe & hanger to prevent insulation being pressed



Airtight Test

■ Airtight Test

✓ Perform the air Tight Test to check leakage with Nitrogen gas


- Block end of each pipe by Pinching & brazing
- Connect one of Gas & Liquid pipe , Install Pressure gage.
- Pressurize nitrogen gas

HP : Gas & Liquid

HR : Gas & Liquid & High pressure

- ❖ Factory setting
- EEV : Full Open
- Sol. valve : Normally Close

If outdoor unit is connected & manifold gauge is not enough then charge through **low pressure gas service valve** for both HP & HR



Airtight Test

■ Airtight Test

※ Test Pressure

- R-32 : 46.9kgf/cm² = 4.6Mpa = 667.2psi

Correlation between pressure and temperature



Temp, 1°C rising → Pres. 0.1 Kg/cm² going up

Temp, 1°C dropping → Pres. 0.1 Kg/cm² going down

(EX): When pressurizing, its condition was 41 kg/cm² at 25°C.
after 24hrs later, it shows 40.5kg/cm² at 20°C, then we can say there is no leak out of the system.

Nitrogen pressurization

1. Maintains **4.6MPa for 24 hours**. If no leakage, then pressure down to 1MPa.
2. If there is pressure drop then find leak point and
3. Maintain **1MPa**(145psi) until connecting the outdoor/indoor units to prevent corrosion in the copper pipes.



Insulation

■ Insulation of pipe

1) Insulate the refrigerant pipe based on the proper thickness of insulator for each pipe size.

The standard condition is **30 °C & less than humidity 85%**.

(If the condition is in high humidity, use one grade thicker)

2) Use EPDM insulation which meets the following condition.

* Seaside, Hot spring, Swimming pool, etc should be treated as high humidity condition

| Pipe | Pipe Size(mm) | Insulator(Cooling, Heating) | | Remark |
|--------|---------------|-----------------------------|-------------------------------|--|
| | | Standard [30°C,85%] | High Humidity [30°C,over 85%] | |
| | | EPDM | | |
| Liquid | Ø6.35~Ø9.52 | 9mm | ← | Heat resisting temperatures Over 120°C |
| | Ø12.70~Ø50.80 | 13mm | ← | |
| Gas | Ø6.35 | 13mm | 19mm | |
| | Ø9.52~Ø25.40 | 19mm | 25mm | |
| | Ø28.58~Ø44.45 | | 32mm | |
| | Ø50.80 | 25mm | 38mm | |


| <EPDM SPEC> | | |
|-------------------------------|---------------------------|----------------------|
| Item | Unit | Standard |
| Density | g/cm ³ | 0.048~0.096 |
| Dimension change rate by heat | % | Below -5 |
| Water absorption rate | g/cm ³ | Below 0.005 |
| Thermal conductivity | Kcal/m·h·°C | Below 0.037 |
| Moisture transpiration factor | ng/(m ² ·s·Pa) | Below 15 |
| Moisture transpiration grade | g/(m ² ·24h) | Below 15 |
| Formaldehyde dispersion | mg/L | There should be none |
| Oxygen rate | % | Over 25 |

Insulation


■ Insulation of pipe

- All the refrigerant pipe & Drainpipe should be insulated to prevent dewing on the pipe.


Case 1



Case 2



Case 3



Insulation

■ Insulation of indoor unit's pipe

- Refrigerant pipe before EEV kit or without EEV kit

You can contact the gas side and liquid side pipes

- The pipes should **not** be **pressed**.

When contacting the gas side and gas side pipe




- Use 1 grade thicker insulator.

- Refrigerant pipe after EEV kit

After EEV kit leave 10mm space between gas and liquid pipe.

When contacting the gas side and liquid side pipe

- Use 1 grade thicker insulator otherwise dewing may occur.



Selection of wire and circuit breaker

■ Wire pipe (tube)

✓ Install the pipe (tube) for power and communication wires separately.

* Piping work can be different in compliance with the regulation in local area




Example)

| Name | Temper grade | Applicable conditions |
|-------------------------------------|--|---|
| Flexible PVC conduit | PVC | Tube is installed indoor and not exposed to outside Ex) it is embedded in concrete structure |
| Class 1 flexible conduit | Galvanized steel sheet | Tube is installed indoor but exposed to outside so there are risk of damage to the protection tube |
| Class 1 PVC coated flexible conduit | Galvanized steel sheet and Soft PVC compound | Tube is installed outdoor and exposed to outside so there are risk of damage to the protection tube and extra waterproof is needed |


Selection of wire and circuit breaker

■ Solderless ring terminal

- Select a solderless ring terminal for a power cable according to the nominal dimensions of cable.
- Apply insulation coating to the connection part of the solderless ring terminal and the power cable.




Power terminal



* Do not use Y-shape for power cable.

Communication terminal



| Nominal dimensions for cable (mm ²) | | 4/6 | | 10 | 16 | 25 | | 35 | | 50 | 70 |
|---|-------------------------|------|------|------|------|------|------|------|------|------|------|
| Nominal dimensions for screw (mm) | | 4 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| B | Standard dimension (mm) | 9.5 | 15 | 15 | 16 | 12 | 16.5 | 16 | 22 | 22 | 24 |
| | Allowance (mm) | ±0.2 | | ±0.2 | ±0.2 | ±0.3 | | ±0.3 | | ±0.3 | ±0.4 |
| D | Standard dimension (mm) | 5.6 | 7.1 | 9 | 11.5 | 13.3 | | 13.5 | 17.5 | | |
| | Allowance (mm) | +0.3 | +0.3 | +0.3 | +0.5 | +0.5 | | +0.5 | +0.5 | -0.2 | -0.4 |
| d1 | Standard dimension (mm) | 3.4 | 4.5 | 5.8 | 7.7 | 9.4 | | 11.4 | 13.3 | | |
| | Allowance (mm) | ±0.2 | | ±0.2 | ±0.2 | ±0.2 | | ±0.3 | ±0.4 | | |
| E | Min. (mm) | 6 | 7.9 | 9.5 | 11 | 12.5 | | 17.5 | 18.5 | | |
| F | Min. (mm) | 5 | 9 | 9 | 13 | 15 | 13 | 13 | 13 | 14 | 20 |
| L | Max. (mm) | 20 | 28.5 | 30 | 33 | 34 | | 38 | 43 | 50 | 51 |
| d2 | Standard dimension (mm) | 4.3 | 8.4 | 8.4 | 8.4 | 8.4 | 8.4 | 8.4 | 8.4 | 8.4 | 8.4 |
| | Allowance (mm) | +0.2 | +0.4 | +0.4 | +0.4 | +0.4 | | +0.4 | +0.4 | +0.4 | +0.4 |
| t | Min. (mm) | 0 | 0 | 0 | 0 | 0 | | 0 | 0 | 0 | 0 |
| | Min. (mm) | 0.9 | | 1.15 | 1.45 | 1.7 | | 1.8 | 1.8 | 2.0 | |

Selection of wire and circuit breaker

■ Wire selection

1. Let your electrical engineer the **MCA** value
(they will care about country regulation & their knowhow)

If they have no idea

1. Check your country regulation and follow
2. Decide how to install the cable (spec of wire will be different)
3. Check the spec of each cable
4. Calculate correct factor by condition
5. Select proper cable size

Installation tip

Keep the installation information



Form

Address can be check(set) easily by following the step


Step 1. Print attached form

Step 2. Put the S/N sticker on the form with No. & Location

Step 3. Using S-net pro 2 set the indoor unit's address & option by matching with S/N



| No. | Model code | S/N sticker | Main Address | RMC Address | Location |
|-----|-------------|-------------|--------------|-------------|------------------------------------|
| 1 | AM012FNNDCH | | 01 | 1A | Office 01 1 st floor |
| 2 | | | | | |
| 3 | | | | | |
| 4 | | | | | |



S-net pro 2 software

| No. | Discharge(Duct) | Error Code | Serial Number |
|-----|-----------------|------------|------------------|
| 2 | -58 F | 702 | Y7KFPAGD3000 01A |
| | -58 F | 129 | Y7KFPAGD3000 08H |
| 0 | -58 F | 0 | Y7KEPAGD3000 28T |
| 6 | -58 F | 0 | Y7K2PAGD3000 08B |
| 1 | -58 F | 0 | Y7K2PAGD3000 01R |
| | -58 F | 129 | Y7KFPAGD3000 23J |
| 06 | -58 F | 0 | Y7KFPAGD3000 02V |

Required tool



Manifold Set (dedicated for R-32)



Flaring Tool (45° Flare)



Vacuum pump & Pressure gauge



Tube cutter & de-burring tool


Hands tools



Torque Wrench



Torch Set & brazing rod



Nitrogen and flow gauge



Scale & leakage detector

Tank intergrated Hydro unit


- Example of application
- Installation information
- Mounting the Hydro unit
- Charging a water into the system

Example of application

1. Space heating + Water heating

An example of field supply scope

- *space heating devices : Radiator or Fan coil unit*
- *water heating devices : Pipe*
- *control devices : Room controller, thermostat, mixing valve*




Example of application















2. Hybrid application (Back-up boiler and solar panel connected)

An example of field supply scope

- *space heating devices : Radiator or Fan coil unit*
- *water heating devices : Pipe*
- *control devices : Room controller, thermostat, mixing valve*
- *Solar system, Back-up boiler*




Accessories

| | | |
|---|---|---|
| Installation Manual (2) | Zone sensor (1x10m, WH) (2) | Temperature Sensor for Mixing Valve (1x15m, BLU) (1) |
|  |  |  |
| Sensor holder of zone sensor and mixing valve (ID Ø6.8 mm) (3) | Sensor clip of zone sensor and mixing valve (3) | Cable-tie for zone sensor and mixing valve (6) |
|  |  |  |
| Aluminum tape for zone sensor and mixing valve (3) | Rubber tape for zone sensor and mixing valve (3) | Insulator for zone sensor and mixing valve (3) |
|  |  |  |
| Connector wire-PV (S/G) (1x2 m, RED) (1) | Tube secondary (1) (only for 260 L Tank model) | Gasket (1) (only for 260 L Tank model) |
|  |  |  |
| Drain-plug out (1) | Cap-drain (2) | |
|  |  | |

Main components


Split



| No. | Part name | Note |
|-----|-----------------------|----------------------------------|
| ① | Refrigerant pipe | ø15.88 (5/8"), Flare nut |
| ② | Refrigerant pipe | ø6.35 (1/4"), Flare nut |
| ③ | Hot water outlet | ø22, Straight pipe |
| ④ | Secondary return | ø22, Straight pipe (260L option) |
| ⑤ | Cold water inlet | ø22, Straight pipe |
| ⑥ | Space heating outlet | ø28, Straight pipe |
| ⑦ | Space heating inlet | ø28, Straight pipe |
| ⑧ | T/P valve | 7bar, 90 °C |
| ⑨ | Pressure relief valve | 3bar, BSPP 1/2" |
| ⑩ | 3way valve | |

| No. | Part name | Note |
|-----|---------------------------|---|
| ⑪ | Anode bar | BSPP 1" |
| ⑫ | Plate heat exchanger | |
| ⑬ | Back-up heater | |
| ⑭ | Drain port | |
| ⑮ | Air vent | BSPP 3/8" |
| ⑯ | Eva-in thermistor | |
| ⑰ | Water-out thermistor | |
| ⑱ | Eva-out thermistor | |
| ⑲ | Water-in thermistor | |
| ⑳ | Tank thermistor | |
| ㉑ | Heater thermistor | |
| ㉒ | Water pump | |
| ㉓ | Water tank | 200L / 260L |
| ㉔ | Manometer | 0~4bar |
| ㉕ | S/D converter | |
| ㉖ | Control box | |
| ㉗ | Booster heater | 3KW |
| ㉘ | Booster heater thermostat | |
| ㉙ | Flow sensor | |
| ㉚ | Expasion vessel | 8L, Pre-charge gas: 0.1MPa, N2, BSPP 3/8" |
| ㉛ | Strainer | |
| ㉜ | Tank drain valve | |
| ㉝ | Drain port | Primary circuit |


Mono



| No. | Part name | Note |
|-----|----------------------------------|----------------------------------|
| ① | Water pipe (Return to heat pump) | ø22, Straight pipe |
| ② | Water pipe (Flow from heat pump) | ø22, Straight pipe |
| ③ | Hot water outlet | ø22, Straight pipe |
| ④ | Secondary return | ø22, Straight pipe (260L option) |
| ⑤ | Cold water inlet | ø22, Straight pipe |
| ⑥ | Space heating outlet | ø28, Straight pipe |
| ⑦ | Space heating inlet | ø28, Straight pipe |
| ⑧ | T/P valve | 7bar, 90 °C |
| ⑨ | Pressure relief valve | 3bar, BSPP 1/2" |
| ⑩ | 3way valve | |

| No. | Part name | Note |
|-----|---------------------------|---|
| ⑪ | Anode bar | BSPP 1" |
| ⑫ | Back-up heater | |
| ⑬ | Drain port | |
| ⑭ | Air vent | BSPP 3/8" |
| ⑮ | Tank thermistor | |
| ⑯ | Heater thermistor | |
| ⑰ | Water pump | |
| ⑱ | Water tank | 200L / 260L |
| ⑲ | Manometer | 0~4bar |
| ⑳ | S/D converter | |
| ㉑ | Control box | |
| ㉒ | Booster heater | 3kW |
| ㉓ | Booster heater thermostat | |
| ㉔ | Flow sensor | |
| ㉕ | Expasion vessel | 8L, Pre-charge gas: 0.1MPa, N2, BSPP 3/8" |
| ㉖ | Strainer | |
| ㉗ | Tank drain valve | |
| ㉘ | Drain port | Primary circuit |

■ Dimensional drawing of Hydro unit



| No | Split | Size | type |
|----|--------------------------------|-----------|---------------|
| ① | Refrigerant (Gas) | Ø15.88 | Flare nut |
| ② | Refrigerant (Liquid) | Ø6.35 | Flare nut |
| ③ | Hot water outlet | Ø22, T1.0 | Straight pipe |
| ④ | Secondary return (260L option) | Ø22, T1.0 | Straight pipe |
| ⑤ | Cold water inlet | Ø22, T1.0 | Straight pipe |
| ⑥ | Space heating outlet | Ø28, T1.2 | Straight pipe |
| ⑦ | Space heating inlet | Ø28, T1.2 | Straight pipe |

| No | Mono | Size | type |
|----|--------------------------------|-----------|---------------|
| ① | Mono outdoor outlet | Ø28, T1.2 | Straight pipe |
| ② | Mono outdoor inlet | Ø28, T1.2 | Straight pipe |
| ③ | Hot water outlet | Ø22, T1.0 | Straight pipe |
| ④ | Secondary return (260L option) | Ø22, T1.0 | Straight pipe |
| ⑤ | Cold water inlet | Ø22, T1.0 | Straight pipe |
| ⑥ | Space heating outlet | Ø28, T1.2 | Straight pipe |
| ⑦ | Space heating inlet | Ø28, T1.2 | Straight pipe |

Installation information


■ Installation of the Indoor unit

- The indoor unit should be installed indoors and meet the following conditions.
- Installation site should be sheltered from frost.
- In area with suitable space for servicing.
- A place with adequate ventilation.
- Where there is no risk of leakage of flammable gases.
- There is a provision for condensate drain and pressure relief valve blow-off.
- The wall for installation is a flat, vertical and non-combustible wall, capable of supporting the operation weight of the

■ Installation space

- Ensure to leave the appropriate space as indicated in the drawing.
- Installation site should be secured with adequate ventilation so that
- the components of hydro unit will not be damaged from overheating.

(Unit : mm)




Installation information

기구작업
추가수정 필요

■ Mounting the Hydro unit

A minimum of two people should lift the unit **by the handles** and **not by the drain pan or pipe work.**




Installation information

■ Base construction and installation of the Tank hydro unit

Manufacturer is not responsible for the damage occurred by not following the installation standards.



1. Considering the vibration and weight of the Tank hydro unit, strength of the base ground must be strong enough to prevent noise and the top part of the base ground has to be flat. Adjust the level controller to make fixed controller has to be min.10 mm higher than level controller.
2. Base ground should be 1.5 times larger than the bottom of the Hydro unit.
3. When concrete construction for Tank hydro unit installation is completed, install an anti-vibration pad($t=20$ mm or more) or an anti-vibration frame(vibration transmissibility=5 % and below) to prevent vibration of the outdoor unit from transferring to the base ground.



Installation information

■ Drain Work

- In the cooling operation, defrost water may be produced from the pipes or tank.
- Produced defrost water must be drained through the drain hole.
- When the drain plug is used, make sure that it is located at a height of 100 mm or more from the floor.
- When the drain plug is used, make sure to install it at one of the positions marked in the figure below.
- When the drain plug is not used, make sure to plug it with the drain cap.





Charging a water into the system

■ Refrigerant pipe work

For all guide lines, specifications regarding refrigerant pipe work between the indoor unit and the outdoor unit,

| | Gas pipe (O.D.) | Liquid pipe (O.D.) |
|--------------|---------------------|--------------------|
| Indoor unit | 15.88 mm (5/8 inch) | 6.35 mm (1/4 inch) |
| Outdoor unit | 15.88 mm (5/8 inch) | 6.35 mm (1/4 inch) |



| Outer diameter [mm(inch)] | Torque (N·m) |
|---------------------------|--------------|
| ø6.35 (1/4") | 14~18 |
| ø9.52 (3/8") | 34~42 |
| ø12.70 (1/2") | 49~61 |
| ø15.88 (5/8") | 68~82 |
| ø19.05 (3/4") | 100~120 |

CAUTION • When connecting the refrigerant pipes, always use 2 wrenches/spanners for tightening or loosening nuts. If not, piping connections can be damaged.

Charging a water into the system



Water pipe work

The hydro unit is equipped with components listed on the table below.

The hot and cold water supply connections are clearly marked on the unit with labels. And service valves are provided.

Whole water plumbing system including Hydro unit shall be installed by a qualified technician and must comply with all relevant European and national regulations.

- Allowable water pressure of hydro unit is maximum 3.0 bar.
- An air-vent valve is integrated on the hydro unit. Please check that air-vent valve is not overtightened so the air-vent valve can release any air out of the system during system operation.



| | No. | Name | Size | Connctions |
|------------------|-----|----------------------|-------------------|-------------------------------|
| Split Hydro unit | ① | Hot water outlet | ø22, T1.0, Copper | Crimp pipe fitting or welding |
| | ② | Sencondary return | ø22, T1.0, Copper | |
| | ③ | Cold water inlet | ø22, T1.0, Copper | |
| | ④ | Space heating outlet | ø28, T1.2, Copper | |
| | ⑤ | Space heating inlet | ø28, T1.2, Copper | |

| | No. | Name | Size | Connctions |
|-----------------|-----|----------------------|-------------------|-------------------------------|
| Mono Hydro unit | ① | Outdoor outlet | ø28, T1.2, Copper | Crimp pipe fitting or welding |
| | ② | Outdoor inlet | ø28, T1.2, Copper | |
| | ③ | Hot water outlet | ø22, T1.0, Copper | |
| | ④ | Sencondary return | ø22, T1.0, Copper | |
| | ⑤ | Cold water inlet | ø22, T1.0, Copper | |
| | ⑥ | Space heating outlet | ø28, T1.2, Copper | |
| | ⑦ | Space heating inlet | ø28, T1.2, Copper | |

Charging a water into the system

■ Charging a water into the system

When filling water, the following start-up procedure should be followed.

1. All system components and pipes must be tested for the presence of leaks.
2. Make-up water assembly or Flushing unit is recommended for installation and service.
3. Before connecting pipes to the hydro unit, Flush water pipes clean to remove contaminants during 1 hours using a flushing unit or tap water pressure if it is adequate (at 2 to 3 bar)
4. Fill water into the hydro unit by opening service valves.
5. Purge the air.(Fill with a flushing unit with sufficient capacity: avoid aerating the water)
6. Circulate for long enough to ensure that all air has been bled from the complete water piping system.

After installations, Commissioning should be performed by qualified representatives.

Unless flushing and air-purging works are performed adequately, It might result in malfunctions.




Flushing unit (or purging cart)

Charging a water into the system

■ Charging a water into the system (Caution !!)


- Check and clean strainer periodically.
- Replace strainer when necessary.
- Its recommended that you flush the system for 4 hours minimum once a per annum.
- Use chemical cleaning agents(Begin with acid , finish with alkali).
- Install **Air vents on the top** of the system
- The complete water circuit, including all pipe must be **insulated** to prevent condensation forming on the surface of the pipe and heat loss to external environment.



Charging a water into the system

■ Charging a water into the system (Caution !!)

- Service space should be secured.
- Water pipe and connections must be cleaned using water.
- If internal water pump capacity is not enough, install external water pump.
- Do not connect electric wire while water charging.
- When initial installation or re-installation required, open the cap to prevent air trap in the unit while charging water.
- The back-up heater vessel shall be full of water before heater is turned on. Confirm if the vessel is empty by opening the pressure relief valve of hydro unit. (OK if water is flowing out)
- It is recommended to install the make-up water assembly to feed small quantities of water to the system automatically, replacing the minor water losses and maintaining the system pressure. This assembly usually consists of a pressure-reducing valve, water filter, check-valve and shut-off valves. In this case, Check-valve must be installed to prevent from contaminating city water.




Charging a water into the system

How to choose an expansion vessel

When it is required to change the default pre-pressure of the expansion vessel(1 bar), keep in mind the following guidelines:

- Use only **dry nitrogen** to set the expansion vessel pre-pressure.
- Improper setting of the expansion vessel pre-pressure will make malfunction of the system.

Therefore, the pre-pressure **should be adjusted by a licensed installer.**



| Installation Height Difference | Water Volume | |
|--------------------------------|--|--|
| | < 220 Litres | > 220 Litres |
| < 7 m | No pre-pressure adjustment required | Actions required: <ul style="list-style-type: none"> □ Pre-pressure must be decreased, calculate according To "Calculating the pre-pressure of the expansion vessel". □ Check if the water volume is lower than maximum allowed Water volume |
| >7 m | Actions required: <ul style="list-style-type: none"> □ Pre-pressure must be increased, calculate the appropriate value following by "Calculating the pre-pressure of the expansion vessel". □ Check if the water volume is lower than maximum allowed water volume | Expansion vessel of the unit too Small for the installation. |

Calculating the pre-pressure of the expansion vessel




$$Pg = \left(\frac{H}{10} + 0.3\right)$$

Pg: Pre-Pressure [bar]
 H: Maximum installation height difference


Charging a water into the system

How to choose a water pump

The illustration below shows the external static pressure of the unit depending on the water flow and the pump setting. When ESP is not enough, additional pump should be installed. In this case, install the PWM control external type pump (Heating type) additionally.



ALL Model : GRUNDFOS UPMM 25-9.5 (Heating Type)





| L1 | L2 | L3 | L4 | B1 | B2 | B3 | H1 | H2 | H3 |
|-----|----|----|----|----|----|----|----|-----|----|
| 130 | 65 | 45 | 65 | 94 | 50 | 52 | 38 | 104 | 82 |

Charging a water into the system

Freeze protection

Freeze protection solutions must use propylene glycol with a toxicity rating of Class 1 as listed in Clinical Toxicology of Commercial Products, 5th Edition.

- Ethylene glycol is toxic and must not be used in the primary water circuit in case of any cross-contamination of the potable circuit.



※ Changing Glycol concentration can cause pressure drop of the system and it can reduce water flow rate.


| Freezing Points of Propylene Glycol – Water Mixtures | | | |
|--|---------------------|--------------------------|---------------------|
| Propylene Glycol [wt. %] | Freezing Point [°C] | Propylene Glycol [wt. %] | Freezing Point [°C] |
| 0 | 0 | 36 | -18 |
| 10 | -3 | 40 | -20 |
| 20 | -7 | 43 | -23 |
| 30 | -12 | 48 | -29 |

Split outdoor unit


- **Installation information**
- **Wiring**

Installation information


Space requirements




* When the air outlet is opposite the wall




* When 3 sides of the outdoor unit are blocked by the wall




* The upper part of the outdoor unit and the air outlet is opposite the wall



* When the air outlet is towards the wall








* The upper part of the outdoor unit and the air outlet is towards the wall



* When front and rear side of the outdoor unit is towards the wall

Installation information

■ Base and anchor bolts





Installation information

■ Drainage

In case there is not enough space for drainage of the unit, additional drain works are required.


- Make **space more than **** between the outdoor unit and the ground for installation of the drain hose.
- Insert the drain plug into the hole on the bottom of the outdoor unit.
- Connect the drain hose to the drain plug.
- Make sure dusts or small branches should not go into the drain hose.
- Cover other drain holes which are not connected to drain plug with drain caps.



Wiring

□ For Power Cable, use the grade H07RN-F or H05RN-F materials.

□ When installing the indoor unit, outdoor unit use the double shielded (Tape aluminium / polyester braid + copper) cable of FROHH2R type.



| Outdoor Unit | Rated | | Voltage Range | | MCA | MFA |
|--------------|-------|---------|---------------|-----|------------------|---------------|
| | Hz | Volts | Min | Max | Min Circuit Amps | Max Fuse Amps |
| AE040RXEDEG | 50 | 220-240 | 198 | 264 | 16A | 20 A |
| AE060RXEDEG | 50 | 220-240 | 198 | 264 | 16 A | 20 A |
| AE090RXEDEG | 50 | 220-240 | 198 | 264 | 22 A | 27.5 A |
| AE090RXEDGG | 50 | 380-415 | 342 | 457 | 10 A | 16.1 A |

| Power supply | Max/Min (V) | Communication cable |
|--------------------|-------------|--------------------------------------|
| 1Φ, 220-240V, 50Hz | ± 10 % | 0.75 ~ 1.5 mm ² , 2 wires |
| 3Φ, 380-415V, 50Hz | | |

Mono outdoor unit



- [Installation information](#)
- [Wiring](#)

Installation information

■ Drainage

In case there is not enough space for drainage of the unit, additional drain works are required.



- Make **space more than **** between the outdoor unit and the ground for installation of the drain hose.
- Insert the drain plug into the hole on the bottom of the outdoor unit.
- Connect the drain hose to the drain plug.
- Make sure dusts or small branches should not go into the drain hose.
- Cover other drain holes which are not connected to drain plug with drain caps.



Installation information

Water pipe connection

- Allowable water pressure of outdoor unit is **maximum 3.0 bar (static Pressure)**.
- Be careful not to deform the unit piping by using excessive force when connecting the piping.
Deformation of the piping can cause the unit to malfunction.
- Always use two wrenches (spanners) for tightening or loosening the water connections, and tighten connections with a torque wrench as specified in below table. If not, connections and parts can be damaged and leaks.



| Name | Tightening Torque | |
|-------------|-------------------|-------------|
| BSP1 | 350~380 kgf•cm | 34 ~ 37 N•m |
| Flow Switch | 72~82 kgf•cm | 7 ~ 8 N•m |



Charging a water into the system

■ Charging a water into the system (Caution !!)

- Installation of Filter / Strainer is **mandatory** for water system. The Filter or Strainer shall be located in front of inlet pipe of PHE. (Filter mesh : #50) The **strainer must be cleaned** after flushing the pipes, and it should be **cleaned periodically**. Replace strainer when necessary.
- In case that **the water piping would be located in a higher position than the air vent of the unit**, it is necessary to **add additional ones** in the highest position of water circuit. The air vent should be located both where **water temperatures are the highest** and where the **height of pipes are the highest**.
- The complete water circuit, including all piping must be **insulated** to prevent condensation forming on the surface of the pipe and heat loss to external environment, as well as prevention of freezing of the outside water piping during winter time. The thickness of the sealing materials must be at **least 9 mm (0.035 W/mK)**.
- MONO Unit **does not have** a pressure relief valve. The valve shall prevent abnormal water pressure from damaging the system by opening at 3.0 bar.



Strainer
Filter mesh
#50



Air vent
for water
piping



Water Pipe
Insulation



Pressure Relief
Valve

Charging a water into the system


■ Flow Sensor

- Flow sensor is not an integrated part of ODU. But the installation is essential to operate MONO Unit.
- Mono type tank integrated hydro unit is basically installed it.
- Flow sensor is provided by Samsung control kit (MIM-E03CN) as a sub component.
- Flow sensor shall be installed described by installation manual of Mono unit or Control kit.
- All electric wiring works shall be implemented by manuals which Samsung provided.

Before completing the installation works, make sure to check if the flow switch is installed in horizontal and if flow direction is in parallel with pipe direction.

(Straight length of In pipe of flow sensor shall have 10 times length in diameter and Straight length of Out pipe of flow sensor shall have 5 times length in diameter)

<Installation Method>





Flow Sensor

Charging a water into the system

Freeze protection

Freeze protection solutions must use propylene glycol with a toxicity rating of Class 1 as listed in Clinical Toxicology of Commercial Products, 5th Edition.

- Ethylene glycol is toxic and must not be used in the primary water circuit in case of any cross-contamination of the potable circuit.



※ Changing Glycol concentration can cause pressure drop of the system and it can reduce water flow rate.

| Freezing Points of Propylene Glycol – Water Mixtures | | | |
|--|---------------------|--------------------------|---------------------|
| Propylene Glycol [wt. %] | Freezing Point [°C] | Propylene Glycol [wt. %] | Freezing Point [°C] |
| 0 | 0 | 36 | -18 |
| 10 | -3 | 40 | -20 |
| 20 | -7 | 43 | -23 |
| 30 | -12 | 48 | -29 |


Charging a water into the system

How to choose a expansion vessel

When it is required to change the default pre-pressure of the expansion vessel(1 bar), keep in mind the following guidelines:

- Use only **dry nitrogen** to set the expansion vessel pre-pressure.
- Improper setting of the expansion vessel pre-pressure will make malfunction of the system.

Therefore, the pre-pressure **should be adjusted by a licensed installer.**



When Expansion vessel has a capacity 8 liters and 1bar pre-charged:

Water volume of total system for reliable performance is minimum 50liters.

Calculating the pre-pressure of the expansion vessel

$$Pg = \left(\frac{H}{10} + 0.3\right)$$


Pg: Pre-Pressure [bar]
 H: Maximum installation height difference

| Installation Height Difference | Water Volume | |
|--------------------------------|---|---|
| | < 220 Litres | > 220 Litres |
| < 7 m | No pre-pressure adjustment required | Actions required: □ Pre-pressure must be decreased, calculate according To “Calculating the pre-pressure of the expansion vessel”. □ Check if the water volume is lower than maximum allowed Water volume |
| >7 m | Actions required: □ Pre-pressure must be increased, calculate the appropriate value following by “Calculating the pre-pressure of the expansion vessel”. □ Check if the water volume is lower than maximum allowed water volume | Expansion vessel of the unit too Small for the installation. |

Wiring

□ For Power Cable, use the grade H07RN-F or H05RN-F materials.

□ When installing the indoor unit, outdoor unit use the double shielded (Tape aluminium / polyester braid + copper) cable of FROHH2R type.



| Outdoor Unit | Rated | | Voltage Range | | MCA | MFA |
|--------------|-------|---------|---------------|-----|------------------|---------------|
| | Hz | Volts | Min | Max | Min Circuit Amps | Max Fuse Amps |
| AE050RXYDEG | 50 | 220-240 | 198 | 264 | 16A | 20 A |
| AE080RXYDEG | 50 | 220-240 | 198 | 264 | 22 A | 27.5 A |
| AE120RXYDEG | 50 | 220-240 | 198 | 264 | 28 A | 35 A |
| AE160RXYDEG | 50 | 220-240 | 198 | 264 | 32 A | 40 A |
| AE080RXYDGG | 50 | 380-415 | 342 | 457 | 10 A | 16.1 A |
| AE120RXYDGG | 50 | 380-415 | 342 | 457 | 10 A | 16.1 A |
| AE160RXYDGG | 50 | 380-415 | 342 | 457 | 12 A | 16.1 A |

| Power supply | Max/Min (V) | Communication cable |
|--------------------|-------------|--------------------------------------|
| 1Φ, 220-240V, 50Hz | ± 10 % | 0.75 ~ 1.5 mm ² , 2 wires |
| 3Φ, 380-415V, 50Hz | | |

External wiring and set up with Hydro unit, Control kit


- Board features
- Information of connecting terminal block
- External contact information

Control box features

■ Control kit control panel (Mono)



■ Hydro unit control panel (Split/Mono)



Main board


Magnet contactor for Backup heater

ELCB

Power in/out terminal


Board features

■ Hydro unit / Control kit board




Board features

■ Main board of Hydro unit & Control kit(mono)



| No. | Connector Description | No. | Connector Description | No. | Connector Description | No. | Connector Description |
|-----|---------------------------------|-----|-----------------------------------|-----|-----------------------------------|-----|--|
| 1 | Main Power (TB-A) | 9 | Water Pump SIG/GND (CNS002) | 17 | EEV (CNS062, BLU) | 25 | BUH/EVA-out/EVA-in/WTR-out/ WTR-in Temp Sensor (CNS043, WHT) |
| 2 | Booster Heater (TB-A1) | 10 | Water Pump SIG/GND (CNS001,WHT) | 18 | DC FAN (CNS808, YEL) | 26 | Backup heater sensor (CNS047, BLK) |
| 3 | External Control (TB-B) | 11 | FR Control (CNS003,GRN) | 19 | Flow sensor (CNS057, WHT) | 27 | Sensor/External Control (CNS051, WHT) |
| 4 | MC-COMMON (CNP003) | 12 | F1/F2, DC12V/GND, F3/F4 (TB-C) | 20 | Water tank sensor (CNS042, YEL) | 28 | Flow switch (CNS041, YEL) |
| 5 | 3way Valve (CNP501) | 13 | DC12V (CNS012, BLU) | 21 | Error/Comp check (CNS081, RED) | 29 | Download (CNS301, BLK) |
| 6 | Heater Thermostat (CNP401, WHT) | 14 | EHS Converter (CNS202, WHT) | 22 | Room sensor (CNS044, WHT) | 30 | Earth (CNP101, WHT) |
| 7 | MC2-A (CNP002) | 15 | Wired Remocon F3/F4 (CNS304, RED) | 23 | External Control (CNS083, RED) | 31 | Sub LED PBA connection (CNS201, WHT) |
| 8 | MC1-A (CNP001) | 16 | PV Signal(S/G) (CNS046) | 24 | Mixing valve sensor (CNS045, BLU) | | |


Information of connecting terminal block



| Terminal No. | Function | Input /output | Max. current | Description | Remark |
|-----------------|---------------|----------------|--------------|--|------------------|
| B1/B6 | Water Pump | AC 230V output | 0.5 A | Water pump operation (maximum input power of pump 100W) | Mandatory |
| B2/B3/B5 | Mixing valve | AC 230V output | 22 mA | Mixing Valve operation | Option |
| B4/B5 | Backup Boiler | AC 230V output | 10 mA | Signal output for Backup Boiler | Option |
| B7/B8 | Water Pump | AC 230V output | 0.5 A | Additional Water pump operation (maximum input power of pump 100W) | Option |
| B9/B10/B11/B12 | 2Way valve #1 | AC 230V output | 22 mA | 2 Way Valve operation for Zone#1 (UFH) | Option |
| B13/B14/B11/B12 | 2Way valve #2 | AC 230V output | 22 mA | 2 Way Valve operation for Zone#2 (FCU) | Option |
| B15/B16/B17/B18 | 3Way valve | AC 230V output | 22 mA | 3 Way Valve operation for DHW | Option |
| B19/B20 | Thermostats | AC 230V output | 22 mA | Power to external thermostat(s) | Option |
| B21/B22 | Thermostat 1 | AC 230V input | 22mA | Thermostat for zone#1 (UFH) Cooling/Heating Signal | Option |
| B23/B24 | Thermostat 2 | AC 230V input | 22mA | Thermostat for zone#2 (FCU) Cooling/Heating Signal | Option |
| B25/B26 | Solar Pump | AC 230V input | 10 mA | Signal input from Solar Pump / DHW Tank Thermostat | Option |

External contact of Hydro unit and Control kit

■ Booster heater (Inside of DHW tank)




Booster heater power out

DHW Tank Temp. (15m)
CNS042(YEL)



| Part | Specification |
|-------------------------|------------------------------------|
| Terminal Block (output) | N, L of TB-A1 |
| Connection load | Direct connection a booster heater |
| Output (N, L) | AC 230V (MAX 20A) |

Sensor
OD 6mm / 103 AT




* Use a correct sensor pocket which is fit for the DHW tank sensor(OD Ø6).
If the gap between the supplied sensor and DHW tank sensor pocket is big, use thermal grease.

External contact of Hydro unit and Control kit


■ Inverter water pump and PWM



PWM signal (Inverter pump only)





- 1. Inverter pump inside of Hydro unit
- 2. Only 1 Inverter pump can be controlled
- 3. Inverter pump




External contact information

■ Additional pump (Fixed)



※ When connect multi water pump to 1 port, Magnet contactor must be used to prevent electrical failure what happened in the port.





• Terminal of this product is for additional water pump and the maximum allowable current is 0.5 A.

External contact information

■ Mixing valve

※ Hydro unit or Control kit power should be turned off before the installation.



| Description | No. of wires | Max. A | Thickness | Supply Scope |
|--------------|--------------|--------|---|------------------------------|
| Mixing valve | 4 | 22 mA | > 0.75 mm ² , H05RN-F or H07RH-F | Field supply (230 V~, Input) |



Select a mixing valve as recommended and install at the entrance position of each zone

| Maker | | BELIMO | SIEMENS | HONEYWELL |
|--------------------|-------------|--------------|--------------------|-------------|
| Model code | 3 Way Valve | R3020-6P3-S2 | VXP45.20-4 (kvs 4) | V5011E1213 |
| | Actuator | LR230A(-S) | SSB31 | ML6420A3015 |
| Running time | | 90 sec. | 150 sec. | 60 sec. |
| FSV(#4046) setting | | 9 | 15 | 6 |




External contact information

■ Mixing valve temperature sensor




Mixing Sensor
(Default, 15 m) CNS045(BLU)




External contact information

Backup boiler





| Description | No. of wires | Max. A | Thickness | Supply Scope |
|----------------|--------------|--------|--|------------------------------|
| Back-up Boiler | 2+ground | 10 mA | 0.75mm ² H05RN-F or H07RN-F | Field supply (230 V~, Input) |



- ※ Control kit power should be turned off before the installation.
- ※ Make sure external control signal of backup boiler must be 230 Vac.
- ※ Heat pump does not work when the back-up boiler operate.
- ※ Heat pump product only supply a power which can operate the on/off switch



When it set back up boiler on the control kit (relay off)

When it order to back up boiler operates (relay on)




External contact information

2 way valves




※ When outlet water temperature reach to lower than 16 °C in cooling mode, UFH loops will be close

| Description | No. of wires | Max. A | Thickness | Supply Scope |
|---|--------------|--------|---|-------------------------------|
| Motorized 2-way valve to shut off UFH loops during cooling. | 2+ground | 22 mA | > 0.75 mm ² , H05RN-F or H07RH-F | Field supply (230 V~, Output) |




External contact information


3 way valve for DHW



| Status | L1 | L2 |
|-------------|-----|-----|
| A (Initial) | OFF | ON |
| B | ON | OFF |




| Description | No. of wires | Max. A | Thickness | Supply Scope |
|---------------------------|--------------|--------|---|------------------------------|
| Diverting type 3way valve | 4 | 22 mA | > 0.75 mm ² , H05RN-F or H07RN-F | Field supply (230 V~, Input) |






External contact information

Thermostats




| description | No. of wires | Max. A | Thickness | Supply Scope |
|-------------------------------------|--------------|--------|---|-----------------------------|
| Room Thermostat for weather control | 4 | 22 mA | > 0.75 mm ² , H05RN-F or H07RH-F | Field supply (230V~, Input) |

※ Contact signal must be “L”.
 If you install two thermostats,
 thermostat2 is prior to thermostat1.



External contact information

■ Solar pump signal for DHW




In operating mode,
signal shall be around 230Vac B/W N&L.

In non-operating mode,
signal shall be around 0Vac B/W N&L.

| Description | No. of wires | Max. A | Thickness | Supply Scope |
|-------------|--------------|--------|--|-----------------------------|
| Solar pump | 2+ground | 10 mA | 0.75mm ² H05RN-F or H07RN-F | Field supply (230V~, Input) |





- Maximum allowable current of each terminal is below 10 mA.
- Ports number B25, B26 are for input port for detection and they do not supply power to a solar pump.



External contact information

■ Peak Control (FSV 5041 = "1")



※ Smart grid signal input connector (2m)

| Main Menu & Code | Sub Menu Function | Field Setting Value | | | | Tank integrated type | | | Wall-mounted type | | | |
|---------------------|--------------------|------------------------------------|----------|------|------|----------------------|-----------|---------|-------------------|-----------|---------|---|
| | | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max | |
| Others Code 50** | Power Peak Control | Application | **41 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) | |
| | | Select forced off parts | **42 | 1 | - | 0 (All) | 0 | 3 | 0 (All) | 0 | 3 | |
| | | Using input voltage | **43 | - | - | 1 (High) | 0 (Low) | 1 | 1 (High) | 0 (Low) | 1 | |
| | PV Control | Frequency Ratio Control | **51 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) | |
| | | Application | **81 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) | |
| | | Setting Temp. Shift Value(Cooling) | **82 | 0.5 | | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | Smart Grid Control | Setting Temp. Shift Value(Heating) | **83 | 0.5 | | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | | Application | **91 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) | |
| | | Setting Temp. Shift Value(Heating) | **92 | 0.5 | | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | Setting Temp. Shift Value(DHW) | **93 | 0.5 | | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | DHW Mode | **94 | - | - | 0 | 0 | 1 (Power) | 0 | 0 | 1 (Power) | | |

. According to FSV (#5042),

If input is "0 (default)", Back up heater (BUH) is unavailable while external contact is high.

If input is "1", Only Compressor(Heat Pump) is available.

If input is "2", Only Booster Heater (BSH) is available.

If input is "3", nothing is available.

. Applying the control when power voltage of input contact is high is default. According to FSV (#5043), it is available to adopt this logic in low condition exceptionally.

. When applying to this logic, SAMSUNG controller come to get "Thermo off" condition for all operation.

External contact information

■ Frequency Ratio Control (FSV 5051 = "1")



| Main Menu & Code | Sub Menu Function | Description | Sub Code | Default | Min | Max | Step | Unit |
|------------------------------------|----------------------------------|----------------------------|----------|---------|---------|-----|------|------|
| Others Code 50** | Outing | Water Out Temp for Cooling | **11 | 25 | 5 | 25 | 1 | °C |
| | | Room Temp for Cooling | **12 | 30 | 18 | 30 | 1 | °C |
| | | Water Out Temp for Heating | **13 | 15 | 15 | 55 | 1 | °C |
| | | Room Temp for Heating | **14 | 16 | 16 | 30 | 1 | °C |
| | | Auto Cooling WL1 Temp | **15 | 25 | 5 | 25 | 1 | °C |
| | | Auto Cooling WL2 Temp | **16 | 25 | 5 | 25 | 1 | °C |
| | | Auto Heating WL1 Temp | **17 | 15 | 15 | 55 | 1 | °C |
| | | Auto Heating WL2 Temp | **18 | 15 | 15 | 55 | 1 | °C |
| | DHW Saving Mode | Target Tank Temp | **19 | 30 | 30 | 70 | 1 | °C |
| | | Temp Difference | **21 | 5 | 0 | 40 | 1 | °C |
| TDM Variable (TDM product Only) | Priority Max. Operation Time | **31 | 30 | 10 | 90 | 5 | min | |
| | Non Priority Min. Operation Time | **32 | 5 | 3 | 60 | 1 | min | |
| | A2A / DHW Priority | **33 | 0 | 0 (A2A) | 1 (DHW) | 1 | - | |
| Power Peak Control | Application | **41 | 0 (No) | 0 | 1 (Yes) | - | - | |
| | Select forced off parts | **42 | 0 (All) | 0 | 3 | 1 | - | |
| | Using input voltage | **43 | 1 (High) | 0 (Low) | 1 | - | - | |
| | Frequency Ratio Control | **51 | 0 (No) | 0 | 1 (Yes) | - | - | |

This is to limit the maximum frequency of the outdoor unit compressor. (if #5051 = 1 "use")

External DC signal Control uses a DC voltage of 0 ~ 10V (0v = 50%, ~ 10v = 150%)



The minimum ~ maximum frequency section being divided with 11 steps of 10%

Switches of unit

- **Switch configuration (Outdoor unit / Hydro unit / Control kit)**
- **Hydro unit / Control kit option setting**
- **External contact information**

Switch configuration

Outdoor unit main board feature

| Optional item | Case I | Case II |
|---------------|---|---|
| Picture |  <p>1 main PCB</p> |  <p>1 main PCB</p> |
| Applied model | <p>AE 080, 090, 120, 160** (outdoor unit)</p> | <p>AE 040, 050, 060** (outdoor unit)</p> |

Switch configuration

Outdoor unit main board – Tact switches



| KEY | KEY operation | 7-segment display |
|-----|--|----------------------------|
| K1 | Press once : Heating test run | "E" "1" "BLANK" "BLANK" |
| | Press twice : Defrost test run | "E" "3" "BLANK" "BLANK" |
| | Press 3times : Finishing test mode | - |
| K2 | Press once : Cooling test run(Heating Only : skip) | "E" "2" "BLANK" "BLANK" |
| | Press twice : Output signal test run | "E" "4" "BLANK" "BLANK" |
| | Press 3 times : Finishing test mode | - |
| K3 | Reset | |
| K4 | View mode | Refer to View mode display |

Case study)

K2 x 2 = The inverter checker mode.

Sequence is as follows.



Wait 10 seconds -> During 5 second, the checked mode transmission with the inverter -> wait 5 seconds

(The checked mode transmission release) -> key operation release



Switch configuration

Outdoor unit main board – View mode by k4 tact switch




| Number of press | Display contents | Display | | | | Units |
|-----------------|------------------------------|-----------------|----------------------------|--|--|-------|
| | | Segment1 | Segment2 | Segment3 | Segment4 | |
| 0 | Communication State | 10s digit of Tx | 1s digit of Tx | 10s digit of Rx | 1s digit of Rx | - |
| 1 | Order frequency | 1 | 100s digit | 10s digit | 1s digit | Hz |
| 2 | Current frequency | 2 | 100s digit | 10s digit | 1s digit | Hz |
| 3 | Inverter Pump output | 3 | 100s digit | 10s digit | 1s digit | % |
| 4 | Outdoor air sensor | 4 | +/- | 10s digit | 1s digit | °C |
| 5 | Discharge sensor | 5 | 100s digit | 10s digit | 1s digit | °C |
| 6 | Eva in sensor | 6 | +/- | 10s digit | 1s digit | °C |
| 7 | Inlet water sensor | 7 | +/- | 10s digit | 1s digit | °C |
| 8 | Outlet water sensor | 8 | +/- | 10s digit | 1s digit | °C |
| 9 | Cond sensor | 9 | +/- | 10s digit | 1s digit | °C |
| 10 | Current | A | 10s digit | 1s digit | First decimal | A |
| 11 | Fan RPM | B | 1000s digit | 100s digit | 10s digit | rpm |
| 12 | Target discharge temperature | C | 100s digit | 10s digit | 1s digit | °C |
| 13 | EEV | D | 1000s digit | 100s digit | 10s digit | step |
| 14 | Protective control | E | 0 : Cooling 1 : Heating | Protective control 0 : No protective control 1 : Freezing 2 : Defrosting 3 : Over-load 4 : Discharge 5 : Total current | Frequency status 0 : Normal 1 : Hold 2 : Down 3 : Up_limit 4 : Down_limit | - |
| 15 | IPM temp. | F | +/- | 10s digit | 1s digit | °C |
| long-1 | Main Micom version | Year(Hex) | Month(Hex) | Day(two digit) | Day(One digit) | - |
| long-1 and 1 | Inverter Micom version | Year(Hex) | Month(Hex) | Day(two digit) | Day(One digit) | - |
| long-1 and 2 | EEPROM version | Year(Hex) | Month(Hex) | Day(two digit) | Day(One digit) | - |

Option setting

■ Outdoor unit option setting by Tact switches

1. Press the K2 switch for 2 seconds, **only if compressor stop**.
2. Press the **K1** switch shortly to change the **option number** (SEG1, SEG2)
3. Press the **K2** switch shortly to change the **option value** (SEG3, SEG4)
4. Press the **K2** switch for **2 seconds to store** the changed option



All the segments blink to indicate the changed option has been stored

- Press **K1 for 2 seconds to return to the original option**. (Before option change store)
- Press **K4 to set all the option values to the factory default**. And then press K2 for 2 seconds
- Press K2 for 2 seconds to store the factory setting values to EEPROM.

Option setting

■ Outdoor option table

| Optional item | SEG1 | SEG2 | SEG3 | SEG4 | Function of the option |
|--------------------------------------|------|------|------|------|-----------------------------------|
| Channel address | 0 | 0 | A | U | Automatic setting (Default) |
| | | | 0 | 0 | Manual setting for channel (0~15) |
| Base heater | 0 | 1 | 0 | 0 | Use (Default) |
| | | | 0 | 1 | Not use |
| Operation mode | 0 | 2 | 0 | 0 | Heat Pump (Default) |
| | | | 0 | 1 | Heating Only |
| Snow accumulation prevention control | 0 | 3 | 0 | 0 | Not use (Default) |
| | | | 0 | 1 | Use |
| Quiet mode | 0 | 4 | 0 | 0 | Quiet Mode 1 (-3 dB) |
| | | | 0 | 1 | Quiet Mode 2 (-5 dB) |
| | | | 0 | 2 | Quiet Mode 3 (-7 dB) |
| | | | 0 | 3 | Quiet Mode 4 (-3 dB) |
| | | | 0 | 4 | TA LARM mode (Default) |
| Power improvement mode | 0 | 5 | 0 | 0 | Not use (Default) |
| | | | 0 | 1 | Use |

Option setting


■ Hydro unit / Control kit – Dip switches



| KEY | ON (Default) | OFF | Remark |
|-------|------------------|--|--|
| DIP 1 | Normal Operation | Emergency Heating Operation | When both DIP 1 and 2 are OFF at the same time, EHS operate emergency heating mode |
| DIP 2 | Normal Operation | Emergency DHW Operation | |
| DIP 3 | Normal Operation | Concrete Curing Function | - |
| DIP 4 | Normal Operation | Outdoor unit power off ->on Error code modification | If you set Dip S/W #4 off in the hydro unit , then the Error E101 still there but After outdoor unit power get back the error will go away. -> can run |


Option setting

■ Hydro unit / Control kit – Dip switches (Emergency space heating operation)

| | Space Heating | |
|--------------------------------|---|---|
| Activation | Dip S/W #1 OFF (Control PBA) |  |
| | FSV #4031 =1 (Backup heater available) | |
| Heat Source | Back up Heater 2 nd stage | |
| Display | Show 'E-op' on the Schedule Display | |
| 3way valve | Room Direction Only | |
| 2way valve | No Zone Control, always open | |
| Water Pump | Following water pump logic under TW2 Control. (ex. 3min-ON, 2min OFF after Thermo off) | |
| Thermo OFF | $Tw3 \geq Ts + 2.0^{\circ}C$ | |
| Thermo ON | $Tw3 < Ts - 2.0^{\circ}C$ | |
| Allowed | E911,E912, Outing Mode, Water Pump, Flow Switch, Anti Freeze, Antipump lock, Electricity failure recovery | |
| Not Allowed or ignoring | Auto, Schedule, Silence, urgent DHW, Disinfection, Tr Control, Thermostat Control, Outdoor unit communication, Back up Boiler, Smart Grid, Eco Level, Viewing Outdoor temperature, Zone Control | |

Option setting

■ Hydro unit / Control kit – Dip switches (Emergency DHW operation)

| | DHW | |
|--------------------------------|---|---|
| Activation | Dip S/W #2 OFF (Control PBA) |  |
| | FSV #3031 =1 (Booster Heater available) | |
| Heat Source | Booster Heater | |
| Display | Show 'E-op' on the Schedule Display | |
| 3way valve | Room Direction Only | |
| 2way valve | No Zone Control, always open | |
| Water Pump | Following water pump logic under TW2 Control. (ex. 3min-ON, 2min OFF after Thermo off) | |
| Thermo OFF | Same as default DHW Control | |
| Thermo ON | Same as default DHW Control | |
| Allowed | E911,E912, Outing Mode, Water Pump, Flow Switch, Anti Freeze, Antipump lock, Electricity failure recovery | |
| Not Allowed or ignoring | Auto, Schedule, Silence, urgent DHW, Disinfection, Tr Control, Thermostat Control, Outdoor unit communication, Back up Boiler, Smart Grid, Eco Level, Viewing Outdoor temperature, Zone Control | |


Option setting

■ Hydro unit (Concrete curing function)

When pipes of floor heating are installed, operation for reinforcing concrete curing is applied. (Period of operation: 23 days)


Entering procedure

1. After turning off the DIP switch K3 of indoor unit (Default ON), power off and on the indoor unit. The operation for concrete curing starts automatically.
(If blackout occurs and communication restarts later, operation will continue.)
2. Temperature of discharge water is controlled as time goes on like below.
3. Remaining days are displayed on the wired remote controller during operation but key operation is unavailable.



| Classification | Initial Heating | | Step raise | | | | Heating | Step down | | | | | Total (Hour) |
|----------------|-----------------|-------------|------------|-------------|------|-------------|---------|-----------|-------------|------|-------------|----|--------------|
| | Time | Temperature | Time | Temperature | Time | Temperature | | Time | Temperature | Time | Temperature | | |
| Time | 96 | 72 | 24 | 24 | 24 | 24 | 144 | 24 | 24 | 24 | 24 | 24 | 552 |
| Temperature | 30 | 55 | 30 | 35 | 40 | 45 | 55 | 50 | 45 | 40 | 35 | 30 | - |

Remaining days are displayed.




* If an error is displayed, concrete curing function does not work.

Field Setting Value

- Service Mode Setting
- Field Setting Value

Service mode Setting

■ Remote controller Overview (MWR-WW00N)



01 Operation status display

- Displays the operation/function settings and statuses.

02 Operation On/Off button (LED display)

- Turns the Air to Water Heat Pump power On/Off

03 Up/Down button

- Moves between items vertically or changes the set temperature.

04 Left/Right button

- Moves between items horizontally or changes the item value.

05 OK button

- Saves your new settings.

06 Save & Return button


- Saves your new settings and returns to the previous step.

07 Option button

- Selects the detailed setting function.

Service mode Setting

■ How to set the service mode with wired remote controller (MWR-WW00N)



1. If you want to use the various additional functions for your Wired Remote Controller, press the and buttons at the same time for more than 3 seconds.
 - The password entry screen appears.
2. Enter the password, 0202, and then press **OK** the button.
 - The settings screen for installation/service mode appears.
3. See the list of additional functions for the Wired Remote Controller on the next page, and then select the desired menu.
 - Once you have entered the setting screen, the current setting appears.
 - Refer to the chart for data setting.
 - Using the / buttons, change the settings and press the button to move to the next setting.
 - Press the **OK** button to save the new setting.
 - Press the button to move to the Home screen.

NOTE

- While setting the data, you can press the button to move to the Home screen after checking the saving status at a pop-up screen.

Service mode Setting

■ Service mode table

1. Unavailable functions are marked inactive and they cannot be set.
2. If communication initialization is needed after the setting, the system will reset automatically and communication will be initialized.

| Step 1 | Step 2 | Step 3 | Description | Default |
|---------------------------|------------------------------|-----------------------|---|-------------------------|
| Service Timer | Service Call Number | | 16-digit phone number Input: Blank, -, 0-9 | - |
| | Last Inspection | | Year, Month, Day | - |
| | Installation Data | | Year, Month, Day | - |
| Quiet Mode Automatic Time | | | Enable/Disable | Disable |
| | | | Entry time to Exit time | PM 10:00 ~ AM 06:00 |
| Indoor Zone Option | Cooling/Heating Selection | | Cooling & Heating/ Heating only | Cooling & Heating |
| | Master/Slave Wired Remote | | Master/Slave | Master |
| | Zone Selection | | Zone1/Zone2 | Zone1 |
| | Standard Temperature | | Water Outlet/Indoor | Water Outlet |
| | Temperature Unit | | Celsius(°C): 1°C/0.5°C/0.1°C | 0.5°C |
| | Temperature Sensor Selection | | Wired Remote Controller/External Temperature Sensor | Wired Remote Controller |
| | Room Temperature Calibration | Reference Temperature | | -9 to 40°C |
| Calibration Value | | | -9 to 40°C | 0°C |

Service mode Setting

■ Service mode table

| Step 1 | Step 2 | Step 3 | Description | Default |
|--------------------|--------------------------------|------------------|------------------------------------|---------|
| Indoor Zone Option | Indoor Zone Status Information | Central : | ON/OFF | - |
| | | Normal Power : | ON/OFF | - |
| | | Mode : | Heat/Cool/Auto | - |
| | | DHW Power : | ON/OFF | - |
| | | DHW Mode : | Economic/Standard/ Power/Forced | - |
| | | Water Pump : | ON/OFF | - |
| | | BUH : | ON/OFF | - |
| | | BSH : | ON/OFF | - |
| | | Flow sensor : | lpm | - |
| | | Inverter Pump : | 0% ~ 100% | - |
| | | EEV Step : | 0~2000Step | - |
| | | Thermostat 1 : | ON/OFF | - |
| | | Thermostat 2 : | ON/OFF | - |
| | | DHW Thermostat : | ON/OFF | - |

Service mode Setting

■ Service mode table

| Step 1 | Step 2 | Step 3 | Description | Default | |
|------------------------|--------------------------------|---------------------------------------|-------------|--------------------------------|---|
| Connection Information | Number of Connection | | 0 to 16 | - | |
| | View Master Indoor Unit | | Address | - | |
| | Master Indoor Zone Information | Serial No. : | | - | - |
| | | Indoor Unit Eva In Temp.(Teva_in) : | | Temperature | - |
| | | Indoor Unit Eva Out Temp.(Teva_out) : | | Temperature | - |
| | | Indoor Unit PHE IN(Tw1) : | | Temperature | - |
| | | Indoor Unit PHE OUT(Tw2) : | | Temperature | - |
| | | DHW Tank Temp. (Tt) : | | Temperature | - |
| | | DHW Mode : | | Economic/Standard/Power/Forced | - |

Service mode Setting

■ Service mode table

| Step 1 | Step 2 | Step 3 | Description | Default |
|------------------------------------|--------------------------------|--------|--------------------|---------|
| Device Information | Micom Code : | | Micom code | - |
| | Program Version : | | Modified date | - |
| | Touch Code : | | Touch IC code | - |
| | Program Version : | | Modified date | - |
| | Graphic Image : | | Graphic image code | - |
| | Program Version : | | Modified date | - |
| Reset All Service Modes | Erase All Service mode data | | - | - |
| | Initialize a remote controller | | - | - |
| Power Master Reset ¹⁾ * | | | - | - |
| ODU K3 Reset | | | - | - |
| Field Setting Value | 10** | | - | - |
| | 20** | | - | - |
| | 30** | | - | - |
| | 40** | | - | - |
| | 50** | | - | - |
| | Simple Setting | | - | - |
| | FSV Upload/Download | | - | - |

Service mode Setting

■ Service mode table

| Step 1 | Step 2 | Step 3 | Description | Default |
|----------------|------------------------|--------------------------------|-------------|---------|
| Self-Test Mode | Self-Test Mode Display | Water Inlet Temp. : | Temperature | - |
| | | Water Outlet Temp. : | Temperature | - |
| | | Backup Heater Outlet Temp. : | Temperature | - |
| | | Mixing Valve Outlet Temp. : | Temperature | - |
| | | Tank Temp. : | Temperature | - |
| | | Indoor Ambient Temp. : | Temperature | - |
| | | Indoor Ambient Temp.(Zone 2) : | Temperature | - |
| | | Water Outlet Temp. (Zone 1) : | Temperature | - |
| | | Water Outlet Temp. (Zone 2) : | Temperature | - |
| | | Thermostat #1(Zone 1) : | Heat/Cool | - |
| | | Thermostat #2(Zone 2) : | Heat/Cool | - |
| | | Solar Panel | ON/OFF | - |

Service mode Setting

■ Service mode table

| Step 1 | Step 2 | Step 3 | Description | Default |
|----------------|------------------------------|--------|-------------|---------|
| Self-Test Mode | Water Pump | | ON/OFF | OFF |
| | Booster Heater | | ON/OFF | OFF |
| | DHW Valve(3Way Valve) | | ON/OFF | OFF |
| | Zone 1 Valve | | ON/OFF | OFF |
| | Backup Heater 1 + Water Pump | | ON/OFF | OFF |
| | Backup Heater 2 + Water Pump | | ON/OFF | OFF |
| | Backup Boiler | | ON/OFF | OFF |
| | Zone 2 Valve | | ON/OFF | OFF |
| | Mixing Valve | | ON/OFF | OFF |

Service mode Setting

■ Service mode table

| Step 1 | Step 2 | Step 3 | Description | Default |
|--------------------|--------------------------------------|--------------|--|---------|
| Indoor Unit Option | Address | Main address | 00 to 4F | - |
| | | RMC address | 00 to FE | - |
| | Product Option ^{2)*} | | Refer to the installation manual of the connected indoor unit or ventilator. | - |
| | Installation Option 1 ^{2)*} | | | - |
| | Installation Option 2 ^{2)*} | | | - |
| | MCU Port | MCU address | 00 to 15 | - |
| | | MCU Port | A to F | - |

1)* Power Master Reset is a setting needed to supply optimized power to wired remote controller when multiple indoor units are connected to wired remote controller in a group.

2)* The total option codes are 24 digits. You can set six digits at a time and it is distinguished by page number. Press the XX button to move to the next page.

Field Setting Value

■ FSV : Menus 10**

 : New

| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | |
|---|----------------------------|-------------|----------|------|------|----------------------|-----|-----|-------------------|-----|-----|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Remote Controller Setting Range Code 10** | Water Out Temp for Cooling | Max | **11 | 1 | °C | 25 | 18 | 25 | 25 | 18 | 25 |
| | | Min | **12 | 1 | °C | 16 | 5 | 18 | 16 | 5 | 18 |
| | Room Temp for Cooling | Max | **21 | 1 | °C | 30 | 28 | 30 | 30 | 28 | 30 |
| | | Min | **22 | 1 | °C | 18 | 18 | 28 | 18 | 18 | 28 |
| | Water Out Temp for Heating | Max | **31 | 1 | °C | 65 | 37 | 65 | 65 | 37 | 65 |
| | | Min | **32 | 1 | °C | 25 | 15 | 37 | 25 | 15 | 37 |
| | Room Temp for heating | Max | **41 | 1 | °C | 30 | 18 | 30 | 30 | 18 | 30 |
| | | Min | **42 | 1 | °C | 16 | 16 | 18 | 16 | 16 | 18 |
| | DHW Tank Temp | Max | **51 | 1 | °C | 55 | 50 | 70 | 55 | 50 | 70 |
| | | Min | **52 | 1 | °C | 40 | 30 | 40 | 40 | 30 | 40 |

✓ Operation range expansion by exchanging to the compressor for R-32

. Max water out temp. for heating : 55 → **65°C**

. Max DHW Tank temp **by Heat pump** : 50 → **55°C**

* New compressor for R-32 : The operation range was expanded more than previous one.

Field Setting Value

■ FSV : Menus 10**

Space Cooling

- * Target water outlet temperature : Upper limit(#1011, Default 25°C, Range : 18 ~ 25°C),
Lower limit(#1012, Default 16°C, Range : 5 ~ 18°C)

With this default FSV settings, user can change the target water outlet temperature within the range of 5 ~ 25°C for cooling

- * Target room temperature : Upper limit(#1021, Default 30°C), Lower limit(#1022, Default 18°C) With this default FSV settings, user can change the target room temperature within the range of 18 ~ 30°C for cooling.

Space Heating

- * Target water outlet temperature : Upper limit(#1031, Default 55°C, Range : 37 ~ 65°C),
Lower limit(#1032, Default 25°C, Range : 15 ~ 37°C)

With this default FSV settings, user can change the target water outlet temperature within the range of 15 ~ 65°C for heating.

- * Target room temperature : Upper limit(#1041, Default 30°C), Lower limit(#1042, Default 16°C) With this default FSV settings, user can change the target room temperature within the range of 16 ~ 30°C for heating.

DHW Heating

- * Target DHW tank temperature : Upper limit(#1051, Default 55°C, Range : 50 ~ 70°C),
Lower limit(#1052, Default 40°C, Range : 30 ~ 40°C)

With this default FSV settings, user can change the target tank temperature within the range of 30 ~ 70°C for DHW heating.

| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | |
|---|----------------------------|-------------|----------|------|------|----------------------|-----|-----|-------------------|-----|-----|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Remote Controller Setting Range Code 10** | Water Out Temp for Cooling | Max | **11 | 1 | °C | 25 | 18 | 25 | 25 | 18 | 25 |
| | | Min | **12 | 1 | °C | 16 | 5 | 18 | 16 | 5 | 18 |
| | Room Temp for Cooling | Max | **21 | 1 | °C | 30 | 28 | 30 | 30 | 28 | 30 |
| | | Min | **22 | 1 | °C | 18 | 18 | 28 | 18 | 18 | 28 |
| | Water Out Temp for Heating | Max | **31 | 1 | °C | 65 | 37 | 65 | 65 | 37 | 65 |
| | | Min | **32 | 1 | °C | 25 | 15 | 37 | 25 | 15 | 37 |
| | Room Temp for heating | Max | **41 | 1 | °C | 30 | 18 | 30 | 30 | 18 | 30 |
| | | Min | **42 | 1 | °C | 16 | 16 | 18 | 16 | 16 | 18 |
| | DHW Tank Temp | Max | **51 | 1 | °C | 55 | 50 | 70 | 55 | 50 | 70 |
| | | Min | **52 | 1 | °C | 40 | 30 | 40 | 40 | 30 | 40 |

Field Setting Value

■ FSV : Menus 20**

 : New

| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | |
|-------------------------------------|---|-------------|----------|------|------|----------------------|-----|-----|-------------------|-----|-----|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Water Law Code 20** | Outdoor Temp for Water Law (Heating) | Point ① | **11 | 1 | °C | -10 | -20 | 5 | -10 | -20 | 5 |
| | | Point ② | **12 | 1 | °C | 15 | 10 | 20 | 15 | 10 | 20 |
| | Water Out Temp for WL1 Heating (WL1-Floor) | Point ① | **21 | 1 | °C | 40 | 17 | 65 | 40 | 17 | 65 |
| | | Point ② | **22 | 1 | °C | 25 | 17 | 65 | 25 | 27 | 65 |
| | Water Out Temp for WL2 Heating (WL2-Fan Coil Unit) | Point ① | **31 | 1 | °C | 50 | 17 | 65 | 50 | 17 | 65 |
| | | Point ② | **32 | 1 | °C | 35 | 17 | 65 | 35 | 17 | 65 |
| | Heating Water Law for Auto Mode | WL Type | **41 | - | - | 1(WL1) | 1 | 2 | 1(WL1) | 1 | 2 |
| | Outdoor Temp for Water Law (Cooling) | Point ① | **51 | 1 | °C | 30 | 25 | 35 | 30 | 25 | 35 |
| | | Point ② | **52 | 1 | °C | 40 | 35 | 45 | 40 | 35 | 45 |
| | Water Out Temp for WL1 Cooling (WL1-Floor) | Point ① | **61 | 1 | °C | 25 | 5 | 25 | 25 | 5 | 25 |
| | | Point ② | **62 | 1 | °C | 18 | 5 | 25 | 18 | 5 | 25 |
| | Water Out Temp for WL2 Cooling (WL2-Fan Coil Unit) | Point ① | **71 | 1 | °C | 18 | 5 | 25 | 18 | 5 | 25 |
| | | Point ② | **72 | 1 | °C | 5 | 5 | 25 | 5 | 5 | 25 |
| | Cooling Water Law for Auto Mode | WL Type | **81 | - | - | 1(WL1) | 1 | 2 | 1(WL1) | 1 | 2 |
| | External Thermostat Application | #1(Floor) | **91 | 1 | - | 0(No) | 0 | 4 | 0(No) | 0 | 4 |
| | | #2(FCU) | **92 | 1 | - | 0(No) | 0 | 4 | 0(No) | 0 | 4 |
| WL interworking control by Wired RC | #3(Wired RC) | **93 | 1 | - | 4 | 1 | 4 | 4 | 1 | 4 | |

Field Setting Value


■ FSV : Menus 20**

Water Law


- This function is used by room sensor of wired remote controller or Thermostat control.

* Only heating mode can use this function during auto mode.

<Heating WL>



<Cooling WL>



Field Setting Value

■ FSV : Menus 2091/2092

External Room Thermostat (Field Option)

(#2091 = 1, #2092 = 1)

Judgment for “Thermo On” or “Thermo Off” : According to **thermostat signal only**.

(#2091 = 2~4, #2092 = 2~4)

Judgement for “Thermo On” or Thermo Off” : According to **thermostat signal** or ***WL follow target outlet temperature (TW2)**.

| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | |
|-------------------------------------|--|-------------|----------|------|-------|----------------------|-----|-------|-------------------|-----|-----|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Water Law Code 20** | Outdoor Temp for Water Law (Heating) | Point ① | **11 | 1 | °C | -10 | -20 | 5 | -10 | -20 | 5 |
| | | Point ② | **12 | 1 | °C | 15 | 10 | 20 | 15 | 10 | 20 |
| | Water Out Temp for WL1 Heating (WL1-Floor) | Point ① | **21 | 1 | °C | 40 | 17 | 65 | 40 | 17 | 65 |
| | | Point ② | **22 | 1 | °C | 25 | 17 | 65 | 25 | 17 | 65 |
| | Water Out Temp for WL2 Heating (WL2-Fan Coil Unit) | Point ① | **31 | 1 | °C | 50 | 17 | 65 | 50 | 17 | 65 |
| | | Point ② | **32 | 1 | °C | 35 | 17 | 65 | 35 | 17 | 65 |
| | Heating Water Law for Auto Mode | WL Type | **41 | - | - | 1(WL1) | 1 | 2 | 1(WL1) | 1 | 2 |
| | Outdoor Temp for Water Law (Cooling) | Point ① | **51 | 1 | °C | 30 | 25 | 35 | 30 | 25 | 35 |
| | | Point ② | **52 | 1 | °C | 40 | 35 | 45 | 40 | 35 | 45 |
| | Water Out Temp for WL1 Cooling (WL1-Floor) | Point ① | **61 | 1 | °C | 25 | 5 | 25 | 25 | 5 | 25 |
| | | Point ② | **62 | 1 | °C | 18 | 5 | 25 | 18 | 5 | 25 |
| | Water Out Temp for WL2 Cooling (WL2-Fan Coil Unit) | Point ① | **71 | 1 | °C | 18 | 5 | 25 | 18 | 5 | 25 |
| | | Point ② | **72 | 1 | °C | 5 | 5 | 25 | 5 | 5 | 25 |
| | Cooling Water Law for Auto Mode | WL Type | **81 | - | - | 1(WL1) | 1 | 2 | 1(WL1) | 1 | 2 |
| | External Thermostat Application | #1(Floor) | **91 | 1 | - | 0(No) | 0 | 4 | 0(No) | 0 | 4 |
| #2(FCU) | | **92 | 1 | - | 0(No) | 0 | 4 | 0(No) | 0 | 4 | |
| WL interworking control by Wired RC | #3(Wired RC) | **93 | 1 | - | 4 | 1 | 4 | 4 | 1 | 4 | |

| Thermostat status | | Signal On | Signal On | Signal Off | Signal Off | Pump status during “Thermo Off” |
|-----------------------|---|-----------|------------|------------|------------|---------------------------------|
| Status by *WL | | Thermo On | Thermo Off | Thermo On | Thermo Off | |
| Value of #2091, #2092 | 1 | On | On | Off | Off | Off (1min delay) |
| | 2 | On | Off | Off | Off | Off (1min delay) |
| | 3 | | | | | On |
| | 4 | | | | | Repeat 3min On / 7min Off |

* WL : Water Law

Field Setting Value

■ FSV : Menus 2093

Wired Remote Controller

(#2093 = 1)

| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | |
|-------------------------------------|--|-------------|----------|------|-------|----------------------|-----|-------|-------------------|-----|-----|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Water Law Code 20** | Outdoor Temp for Water Law (Heating) | Point ① | **11 | 1 | °C | -10 | -20 | 5 | -10 | -20 | 5 |
| | | Point ② | **12 | 1 | °C | 15 | 10 | 20 | 15 | 10 | 20 |
| | Water Out Temp for WL1 Heating (WL1-Floor) | Point ① | **21 | 1 | °C | 40 | 17 | 65 | 40 | 17 | 65 |
| | | Point ② | **22 | 1 | °C | 25 | 17 | 65 | 25 | 17 | 65 |
| | Water Out Temp for WL2 Heating (WL2-Fan Coil Unit) | Point ① | **31 | 1 | °C | 50 | 17 | 65 | 50 | 17 | 65 |
| | | Point ② | **32 | 1 | °C | 35 | 17 | 65 | 35 | 17 | 65 |
| | Heating Water Law for Auto Mode | WL Type | **41 | - | - | 1(WL1) | 1 | 2 | 1(WL1) | 1 | 2 |
| | Outdoor Temp for Water Law (Cooling) | Point ① | **51 | 1 | °C | 30 | 25 | 35 | 30 | 25 | 35 |
| | | Point ② | **52 | 1 | °C | 40 | 35 | 45 | 40 | 35 | 45 |
| | Water Out Temp for WL1 Cooling (WL1-Floor) | Point ① | **61 | 1 | °C | 25 | 5 | 25 | 25 | 5 | 25 |
| | | Point ② | **62 | 1 | °C | 18 | 5 | 25 | 18 | 5 | 25 |
| | Water Out Temp for WL2 Cooling (WL2-Fan Coil Unit) | Point ① | **71 | 1 | °C | 18 | 5 | 25 | 18 | 5 | 25 |
| | | Point ② | **72 | 1 | °C | 5 | 5 | 25 | 5 | 5 | 25 |
| | Cooling Water Law for Auto Mode | WL Type | **81 | - | - | 1(WL1) | 1 | 2 | 1(WL1) | 1 | 2 |
| | External Thermostat Application | #1(Floor) | **91 | 1 | - | 0(No) | 0 | 4 | 0(No) | 0 | 4 |
| #2(FCU) | | **92 | 1 | - | 0(No) | 0 | 4 | 0(No) | 0 | 4 | |
| WL interworking control by Wired RC | #3(Wired RC) | **93 | 1 | - | 4 | 1 | 4 | 4 | 1 | 4 | |

Judgment for “Thermo On” or “Thermo Off” : According to **room temp. sensor of wired remote controller only**.

(#2093 = 2~4)

Judgement for “Thermo On” or Thermo Off” : According to **room temp. sensor of wired remote controller** or ***WL follow target outlet temperature (TW2)**.

| Status by wired remote controller | | Thermo On | Thermo On | Thermo Off | Thermo Off | Pump status during “Thermo Off” |
|-----------------------------------|---|-----------|------------|------------|------------|---------------------------------|
| Status by *WL | | Thermo On | Thermo Off | Thermo On | Thermo Off | |
| Value of #2093 | 1 | On | On | Off | Off | Off (1min delay) |
| | 2 | On | Off | Off | Off | Off (1min delay) |
| | 3 | | | | | On |
| | 4 | | | | | Repeat 3min On / 7min Off |

* WL : Water Law

Field Setting Value

■ FSV : Menus 30**

: New

| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | |
|---------------------|----------------------------|-----------------------------------|----------|------|-----------|----------------------|--------|---------|-------------------|--------|---------|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| DHW Code 30** | Domestic Hot Water Tank | Application | **11 | - | - | 1(Yes) | 0 | 2 | 0(No) | 0 | 2 |
| | Heat Pump | Max Temp | **21 | 1 | °C | 55 | 45 | 55 | 55 | 45 | 55 |
| | | Stop | **22 | 1 | °C | 0 | 0 | 10 | 2 | 0 | 10 |
| | | Start | **23 | 1 | °C | 5 | 5 | 30 | 5 | 5 | 30 |
| | | Min. Space heating Operation time | **24 | 1 | min | 5 | 1 | 20 | 5 | 1 | 20 |
| | | Max. DHW operation time | **25 | 5 | min | 30 | 5 | 95 | 30 | 5 | 95 |
| | | Max. Space heating Operation time | **26 | 0.5 | hour | 3 | 0.5 | 10 | 3 | 0.5 | 10 |
| | Booster Heater | Application | **31 | - | - | 1(On) | 0(Off) | 1 | 1(On) | 0(Off) | 1 |
| | | Delay Time | **32 | 5 | min | 20 | 20 | 95 | 20 | 20 | 95 |
| | | Overshoot | **33 | 1 | °C | 0 | 0 | 4 | 0 | 0 | 4 |
| | Disinfection | Application | **41 | - | - | 1(On) | 0(Off) | 1 | 1(On) | 0(Off) | 1 |
| | | Interval | **42 | 1 | day | Fri(5) | Sun(0) | All(7) | Fri(5) | Sun(0) | All(7) |
| | | Start Time | **43 | 1 | o'clock | 23 | 0 | 23 | 23 | 0 | 23 |
| | | Target Temp | **44 | 5 | °C | 70 | 40 | 70 | 70 | 40 | 70 |
| | | Duration | **45 | 5 | min | 10 | 5 | 60 | 10 | 5 | 60 |
| | | Max time | **46 | 1 | hour | 8 | 1 | 24 | 8 | 1 | 24 |
| | Forced DHW operation | Timer OFF Function | **51 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |
| | | Timer Duration | **52 | 1 | (x10) min | 6 | 3 | 30 | 6 | 3 | 30 |
| | Solar Panel/DHW Thermostat | H/P Combination | **61 | 1 | - | 0(No) | 0 | 2 | 0(No) | 0 | 2 |
| | Direction of DHW valve | DHW Tank | **71 | - | - | 0(Room) | 0 | 1(Tank) | 0(Room) | 0 | 1(Tank) |
| | Energy metering | BUH 1 step capacity | **81 | 1 | kW | 2 | 1 | 6 | 2 | 1 | 6 |
| BUH 2 step capacity | | **82 | 1 | kW | 2 | 0 | 6 | 2 | 0 | 6 | |
| BSH capacity | | **83 | 1 | kW | 3 | 1 | 6 | 3 | 1 | 6 | |


Field Setting Value

■ FSV : Menus 302* / 303*


| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | | |
|---------------------|-------------------|-----------------------------------|----------|------|------|----------------------|-------|--------|-------------------|-------|--------|---|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Stop | Unit | Default | Min | Max | Default | Min | Max | |
| DHW Code 30** | Heat Pump | Max Temp | **21 | 1 | °C | 55 | 45 | 55 | 55 | 45 | 55 | |
| | | Stop | **22 | 1 | °C | 0 | 0 | 10 | 2 | 0 | 10 | |
| | | Start | **23 | 1 | °C | 5 | 5 | 30 | 5 | 5 | 30 | |
| | | Min. Space heating Operation time | **24 | 1 | min | 5 | 1 | 20 | 5 | 1 | 20 | |
| | | Max. DHW operation time | **25 | 5 | min | 30 | 5 | 95 | 30 | 5 | 95 | |
| | | Max. Space heating Operation time | **26 | 0.5 | hour | 3 | 0.5 | 10 | 3 | 0.5 | 10 | |
| | Booster Heater | Application | **31 | - | - | | 1(On) | 0(Off) | 1 | 1(On) | 0(Off) | 1 |
| | | Delay Time | **32 | 5 | min | 20 | 20 | 95 | 20 | 20 | 95 | |
| | | Overshoot | **33 | 1 | °C | 0 | 0 | 4 | 0 | 0 | 4 | |
| | | | | | | | | | | | | |

- 302* : Heat pump variables for tank temp. control and combination with booster heater
- 303* : Booster heater variables for combination with heat pump

[DHW Tank water temperature thermo on/off control]



[Time variation control of DHW and space heating mode]




Field Setting Value

FSV : Menus 302* / 303*

| Main Menu & Code | Sub Menu Function | Description | Sub Code | Stop | Unit | Tank integrated type | | | Wall-mounted type | | |
|------------------|-------------------|-----------------------------------|----------|------|------|----------------------|--------|-----|-------------------|--------|-----|
| | | | | | | Default | Min | Max | Default | Min | Max |
| DHW Code 30** | Heat Pump | Max Temp | **21 | 1 | °C | 55 | 45 | 55 | 55 | 45 | 55 |
| | | Stop | **22 | 1 | °C | 0 | 0 | 10 | 2 | 0 | 10 |
| | | Start | **23 | 1 | °C | 5 | 5 | 30 | 5 | 5 | 30 |
| | | Min. Space heating Operation time | **24 | 1 | min | 5 | 1 | 20 | 5 | 1 | 20 |
| | | Max. DHW operation time | **25 | 5 | min | 30 | 5 | 95 | 30 | 5 | 95 |
| | | Max. Space heating Operation time | **26 | 0.5 | hour | 3 | 0.5 | 10 | 3 | 0.5 | 10 |
| | Booster Heater | Application | **31 | - | - | 1(On) | 0(Off) | 1 | 1(On) | 0(Off) | 1 |
| | | Delay Time | **32 | 5 | min | 20 | 20 | 95 | 20 | 20 | 95 |
| | | Overshoot | **33 | 1 | °C | 0 | 0 | 4 | 0 | 0 | 4 |
| | | | | | | | | | | | |

- 302* : Heat pump variables for tank temp. control and combination with booster heater
- 303* : Booster heater variables for combination with heat pump


[Time variation control of Heat pump and booster heater of DHW]



[Thermo on/off control of Heat pump and Booster Heater]

| Condition | Operation |
|-----------------------------|--|
| Setting temp. of DHW > 50°C | ① BSH Thermo Off ≥ Setting temp. BSH Thermo On < Thermo Off temp. – 2°C ② H/P Thermo Off ≥ Setting temp. H/P Thermo On < Setting temp. – FSV #3023 (5°C) |
| Setting temp. of DHW ≤ 50°C | ① BSH Thermo Off ≥ Setting temp. BSH Thermo On < Setting temp. – FSV #3023 (5°C) ② H/P Thermo Off ≥ Setting temp. H/P Thermo On < Setting temp. – FSV #3023 (5°C) |

- ※ FSV #3031 should be set as “1(On)” to use Booster Heater.
- ※ FSV #4022 should be set as “0(both) or 2(booster heater) to use booster heater otherwise the booster heater can be operated in case of no Backup Heater demand.




Field Setting Value

■ FSV : Menus 304*

- 304* : Periodical disinfection heating of water tank

| Main Menu & Code | Sub Menu Function | Field Setting Value | | | Tank integrated type | | | Wall-mounted type | | | |
|------------------|-------------------|---------------------|----------|------|----------------------|---------|--------|-------------------|---------|--------|--------|
| | | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| DHW Code 30** | Disinfection | Application | **41 | - | | 1(On) | 0(Off) | 1 | 1(On) | 0(Off) | 1 |
| | | Interval | **42 | 1 | day | Fri(5) | Sun(0) | All(7) | Fri(5) | Sun(0) | All(7) |
| | | Start Time | **43 | 1 | o'clock | 23 | 0 | 23 | 23 | 0 | 23 |
| | | Target Temp | **44 | 5 | °C | 70 | 40 | 70 | 70 | 40 | 70 |
| | | Duration | **45 | 5 | min | 10 | 5 | 60 | 10 | 5 | 60 |
| | | Max time | **46 | 1 | hour | 8 | 1 | 24 | 8 | 1 | 24 |

[Time variation control of Heat pump and booster heater of DHW]



* If the temp. doesn't rise during disinfection, it will occur the E919.

※ FSV #3041 should be set to use Disinfection mode.

※ FSV #3031 setting and DHW thermo on signal is ignored in case of disinfection mode.

Field Setting Value

■ FSV : Menus 30**

- 305* : Forced DHW operation

| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | |
|---------------------|----------------------------|---------------------|----------|------|-----------|----------------------|-----|---------|-------------------|-----|---------|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| DHW Code 30** | Forced DHW operation | Timer OFF Function | **51 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |
| | | Timer Duration | **52 | 1 | (x10) min | 6 | 3 | 30 | 6 | 3 | 30 |
| | Solar Panel/DHW Thermostat | H/P Combination | **61 | 1 | - | 0(No) | 0 | 2 | 0(No) | 0 | 2 |
| | Direction of DHW valve | DHW Tank | **71 | - | - | 0(Room) | 0 | 1(Tank) | 0(Room) | 0 | 1(Tank) |
| | Energy metering | BUH 1 step capacity | **81 | 1 | kW | 2 | 1 | 6 | 2 | 1 | 6 |
| | | BUH 2 step capacity | **82 | 1 | kW | 2 | 0 | 6 | 2 | 0 | 6 |
| | | BSH capacity | **83 | 1 | kW | 3 | 1 | 6 | 3 | 1 | 6 |

- . FSV #3011, should be set "1" (Yes) to use Forced DHW operation .
- . Forced DHW mode shall be working depending on Timer setting (#3051, #3052).

- 3061 : Solar panel Forced DHW operation



- . #3061 "0" : Solar panel is not used.
- . #3061 "1" : Solar panel is used
 - * Whenever solar panel on signal input -> Comp. off(only in DHW mode), Booster Heater off
 - * Solar panel and heat pump are able to operate simultaneously except DHW mode.
- . #3061 "2" : Solar panel is not used and DHW thermostat is used.

Field Setting Value

■ FSV : Menus 308*

- 308* : Energy metering

| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Tank integrated type | | | Wall-mounted type | | |
|------------------|----------------------------|---------------------|----------|------|-----------|----------------------|-----|---------|-------------------|-----|---------|
| | | | | | | Default | Min | Max | Default | Min | Max |
| DHW Code 30** | Forced DHW operation | Timer OFF Function | **51 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |
| | | Timer Duration | **52 | 1 | (x10) min | 6 | 3 | 30 | 6 | 3 | 30 |
| | Solar Panel/DHW Thermostat | H/P Combination | **61 | 1 | - | 0(No) | 0 | 2 | 0(No) | 0 | 2 |
| | | DHW Tank | **71 | - | - | 0(Room) | 0 | 1(Tank) | 0(Room) | 0 | 1(Tank) |
| | Energy metering | BUH 1 step capacity | **81 | 1 | kW | 2 | 1 | 6 | 2 | 1 | 6 |
| | | BUH 2 step capacity | **82 | 1 | kW | 2 | 0 | 6 | 2 | 0 | 6 |
| | BSH capacity | **83 | 1 | kW | 3 | 1 | 6 | 3 | 1 | 6 | |



- To check energy information of system, user should set to FSV #308* according to heater (BUH, BSH) capacity.

. In order to get the exact value, this should be set.

* The FSV #4021 should be set to BUH (Back Up Heater) use.

Field Setting Value

■ FSV : Menus 40**

 : New


| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | |
|----------------------|-------------------|---------------------------|----------|------|--------------|----------------------|---------|---------|-------------------|---------|---------|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Heating Code 40** | Heat Pump | Heating/DHW Priority | **11 | - | - | 0(DHW) | 0 | 1(Heat) | 0(DHW) | 0 | 1(Heat) |
| | | Outdoor Temp for Priority | **12 | 1 | °C | 0 | -15 | 20 | 0 | -15 | 20 |
| | | Heating Off | **13 | 1 | °C | 35 | 14 | 35 | 35 | 14 | 35 |
| | Backup Heater | Application | **21 | - | - | 0(No) | 0 | 2 | 0(No) | 0 | 2 |
| | | BUH/BSH Priority | **22 | 1 | - | 2(BSH) | 0(Both) | 2(BSH) | 0(Both) | 0(Both) | 2(BSH) |
| | | Cold weather compensation | **23 | - | - | 1(Yes) | 0(No) | 1 | 1(Yes) | 0(No) | 1 |
| | | Threshold Temp | **24 | 1 | °C | 0 | -25 | 35 | 0 | -25 | 35 |
| | | Defrost Backup Temp. | **25 | 5 | °C | 15 | 10 | 55 | 15 | 10 | 55 |
| | Backup Boiler | Application | **31 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |
| | | Boiler Priority | **32 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |
| | | Threshold Temp | **33 | 1 | °C | -15 | -20 | 5 | -15 | -20 | 5 |
| | Mixing Valve | Application | **41 | 1 | - | 0(No) | 0 | 2 | 0(No) | 0 | 2 |
| | | Target ΔT(Heating) | **42 | 1 | °C | 10 | 5 | 15 | 10 | 5 | 15 |
| | | Target ΔT(Cooling) | **43 | 1 | °C | 10 | 5 | 15 | 10 | 5 | 15 |
| | | Control factor | **44 | 1 | - | 2 | 1 | 5 | 2 | 1 | 5 |
| | | Control interval | **45 | 1 | min | 2 | 1 | 30 | 2 | 1 | 30 |
| | | Running Time | **46 | 3 | (x10) sec | 9 | 6 | 24 | 9 | 6 | 24 |
| | Inverter Pump | Application | **51 | - | - | 1(Yes) | 0 | 2 | 1(Yes) | 0 | 2 |
| | | Target ΔT | **52 | 1 | °C | 5 | 2 | 8 | 5 | 2 | 8 |
| | | Control factor | **53 | 1 | - | 2 | 1 | 3 | 2 | 1 | 3 |
| | Zone Control | Application | **61 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |

Field Setting Value

■ FSV : Menus 401*

- 401* : Heat pump variables for space heating

| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Tank integrated type | | | Wall-mounted type | | |
|-------------------|-------------------|---------------------------|----------|------|------|----------------------|-----|---------|-------------------|-----|---------|
| | | | | | | Default | Min | Max | Default | Min | Max |
| Heating Code 40** | Heat Pump | Heating/DHW Priority | ** 11 | - | - | 0(DHW) | 0 | 1(Heat) | 0(DHW) | 0 | 1(Heat) |
| | | Outdoor Temp for Priority | ** 12 | 1 | °C | 0 | -15 | 20 | 0 | -15 | 20 |
| | | Heating Off | ** 13 | 1 | °C | 35 | 14 | 35 | 35 | 14 | 35 |



FSV #4011 for DHW priority is set to “0(DHW)” (Default) as a default. Space heating gets a priority by setting FSV #4011 “1”, but this is only valid when the outdoor temperature is lower than the specified temperature defined by FSV #4012.

Field Setting Value

■ FSV : Menus 402*

- 402* : Backup Heater variables for space heating

| Main Menu & Code | Sub Menu Function | Field Setting Value | | | | Tank integrated type | | | Wall-mounted type | | |
|-------------------|-------------------|---------------------------|----------|------|------|----------------------|---------|--------|-------------------|---------|--------|
| | | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Heating Code 40** | Backup Heater | Application | **21 | - | - | 0(No) | 0 | 2 | 0(No) | 0 | 2 |
| | | BUH/BSH Priority | **22 | 1 | - | 2(BSH) | 0(Both) | 2(BSH) | 0(Both) | 0(Both) | 2(BSH) |
| | | Cold weather compensation | **23 | - | - | 1(Yes) | 0(No) | 1 | 1(Yes) | 0(No) | 1 |
| | | Threshold Temp. | **24 | 1 | °C | 0 | -25 | 35 | 0 | -25 | 35 |
| | | Defrost Backup Temp. | **25 | 5 | °C | 15 | 10 | 55 | 15 | 10 | 55 |

. **FSV #4021 should be set to 1 (Use both BUH 1 and BUH 2) or 2 (Use a BUH 1) to use electric backup heater in hydro unit as an additional heat source.**

. To compensate the lowered heat pump heating performance under very cold weather conditions, the FSV #4023 should be set to “1(On, Default)”.

The threshold temperature to use backup heater for cold weather compensation: FSV #4024, Default “0°C”, Range -25 ~ 35°C

The backup heater operation is restricted to save energy in the threshold temperature range.

. The FSV #4022 for backup heater priority should be set to “2 (BSH, Default)” or “0” (Both), or “1” (backup) to use backup heater.

If not (Booster heater priority), the backup heater can be operated in case of no booster heater demand.

. The threshold temperature for backup heater operation during defrost mode to prevent cold draft because of chilled water can be controlled by adjusting FSV #4025. Under FSV #4025 of water outlet temperature, backup heater Will be turned on.

Field Setting Value

■ FSV : Menus 403*

- 403* : External Backup Boiler for space heating


| Field Setting Value | | | | | Tank integrated type | | | Wall-mounted type | | | |
|---------------------|-------------------|--------------------|----------|------|----------------------|---------|-----|-------------------|---------|-----|--------|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Heating Code 40** | Backup Boiler | Application | **31 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |
| | | Boiler Priority | **32 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |
| | | Threshold Temp | **33 | 1 | 'C | -15 | -20 | 5 | -15 | -20 | 5 |
| | Mixing Valve | Application | **41 | 1 | - | 0(No) | 0 | 2 | 0(No) | 0 | 2 |
| | | Target ΔT(Heating) | **42 | 1 | 'C | 10 | 5 | 15 | 10 | 5 | 15 |
| | | Target ΔT(Cooling) | **43 | 1 | 'C | 10 | 5 | 15 | 10 | 5 | 15 |
| | | Control factor | **44 | 1 | - | 2 | 1 | 5 | 2 | 1 | 5 |
| | | Control interval | **45 | 1 | min | 2 | 1 | 30 | 2 | 1 | 30 |
| | | Running Time | **46 | 3 | (x10)sec | 9 | 6 | 24 | 9 | 6 | 24 |

- . **FSV #4031 should be set to “1 (Yes)” to use a backup boiler as an additional heat source.** (default: “0 (No installation)”)
- . Priority of backup boiler and heat pump is defined by FSV #4032 (default: “0 (OFF)”)
- . To compensate the lowered heat pump heating performance under very cold weather conditions, the backup boiler operates instead of heat pump under the threshold temperature (FSV #4033, Default “-15°C”, Range -20 ~ 5°C).

Field Setting Value

FSV : Menus 404*

- 404* : Mixing valve installation




| Field Setting Value | | | | | Tank integrated type | | | Wall-mounted type | | | | |
|---------------------|-------------------|--------------------|----------|------|----------------------|----------|-------|-------------------|---------|-------|--------|----|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max | |
| Heating Code 40** | Backup Boiler | Application | **31 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) | |
| | | Boiler Priority | **32 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) | |
| | | Threshold Temp | **33 | 1 | - | °C | -15 | -20 | 5 | -15 | -20 | 5 |
| | Mixing Valve | Application | **41 | 1 | - | - | 0(No) | 0 | 2 | 0(No) | 0 | 2 |
| | | Target ΔT(Heating) | **42 | 1 | - | °C | 10 | 5 | 15 | 10 | 5 | 15 |
| | | Target ΔT(Cooling) | **43 | 1 | - | °C | 10 | 5 | 15 | 10 | 5 | 15 |
| | | Control factor | **44 | 1 | - | - | 2 | 1 | 5 | 2 | 1 | 5 |
| | | Control interval | **45 | 1 | - | min | 2 | 1 | 30 | 2 | 1 | 30 |
| | | Running Time | **46 | 3 | - | (x10)sec | 9 | 6 | 24 | 9 | 6 | 24 |

. The FSV #4041 should be set to "1 or 2" to use mixing valve.

※ #4041 =1 : Controlled based on the temperature difference (4042, 4043)

※ #4041 =2 : Controlled based on the temperature difference of the WL value

ex) Heating




- The mixing valve is controlled based on the FCU WL value.
- As the #4044 value increases and the #4045 value decreases, the control speed increases. (Temperature hunting may occur if the control speed increases depending on the load.)
- The additional pump and mixing valve should be purchased separately. TW4 sensor is included in the product accessories.
- TW3 : Water temp. sensor 3

Field Setting Value

■ FSV : Menus 405*

- 405* : Inverter pump control

| Field Setting Value | | | | | | Tank integrated type | | | Wall-mounted type | | | |
|---------------------|-------------------|----------------|-------------|------|------|----------------------|-------|-----|-------------------|-------|-----|--------|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max | |
| Heating Code 40** | Inverter Pump | Application | **51 | - | - | 1(Yes) | 0 | 2 | 1(Yes) | 0 | 2 | |
| | | Target ΔT | **52 | 1 | - | °C | 5 | 2 | 8 | 5 | 2 | 8 |
| | | Control factor | **53 | 1 | - | - | 2 | 1 | 3 | 2 | 1 | 3 |
| | | Zone Control | Application | **61 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |



The FSV #4051 should be set to “1 or 2” to use inverter pump control.

※ #4051 =1 : Use (Max 100%)


※ #4051 =2 : Use (Max 70%)

The FSV #4052 is for adjusting temperature difference between Tw2 and Tw1.

$$* \text{ Output signal of Inverter pump}(\%) = \text{Current Inverter pump output}(\%) + ((\text{Tw2}-\text{Tw1}- \text{FSV \#4052}) * \text{FSV 4053})$$

Field Setting Value

■ FSV : Menus 4061 - 4061 : Zone control



| | | Field Setting Value | | | | Tank integrated type | | | Wall-mounted type | | |
|-------------------|-------------------|---------------------|----------|------|------|----------------------|-----|--------|-------------------|-----|--------|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Heating Code 40** | Inverter Pump | Application | ** 51 | - | - | 1(Yes) | 0 | 2 | 1(Yes) | 0 | 2 |
| | | Target ΔT | ** 52 | 1 | 'C | 5 | 2 | 8 | 5 | 2 | 8 |
| | | Control factor | ** 53 | 1 | - | 2 | 1 | 3 | 2 | 1 | 3 |
| | Zone Control | Application | ** 61 | - | - | 0(No) | 0 | 1(Yes) | 0(No) | 0 | 1(Yes) |

The FSV #4061 should be set to “1(Yes)” to zone control.

Field Setting Value

■ FSV : Menus 50**

 : New

| Main Menu & Code | Sub Menu Function | Field Setting Value | | | | Tank integrated type | | | Wall-mounted type | | |
|---------------------|-------------------------|-----------------------------------|----------|------|------|----------------------|--------------|-----------|-------------------|--------------|-----------|
| | | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Others Code 50** | Outing | Water Out Temp for Cooling | **11 | 1 | °C | 25 | 5 | 25 | 25 | 5 | 25 |
| | | Room Temp for Cooling | **12 | 1 | °C | 30 | 18 | 30 | 30 | 18 | 30 |
| | | Water Out Temp for Heating | **13 | 1 | °C | 15 | 15 | 55 | 15 | 15 | 55 |
| | | Room Temp for Heating | **14 | 1 | °C | 16 | 16 | 30 | 16 | 16 | 30 |
| | | Auto Cooling WL1 Temp | **15 | 1 | °C | 25 | 5 | 25 | 25 | 5 | 25 |
| | | Auto Cooling WL2 Temp | **16 | 1 | °C | 25 | 5 | 25 | 25 | 5 | 25 |
| | | Auto Heating WL1 Temp | **17 | 1 | °C | 15 | 15 | 55 | 15 | 15 | 55 |
| | | Auto Heating WL2 Temp | **18 | 1 | °C | 15 | 15 | 55 | 15 | 15 | 55 |
| | Target Tank Temp | **19 | 1 | °C | 30 | 30 | 70 | 30 | 30 | 70 | |
| | DHW Saving Mode | Temp Difference | **21 | 1 | °C | 5 | 0 | 40 | 5 | 0 | 40 |
| | | Saving Mode | **22 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Thermo On Temp during Saving Mode | **23 | 1 | °C | 25 | 0 | 40 | 25 | 0 | 40 |
| | Power Peak Control | Application | **41 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Select forced off parts | **42 | 1 | - | 0 (All) | 0 | 3 | 0 (All) | 0 | 3 |
| | | Using input voltage | **43 | - | - | 1 (High) | 0 (Low) | 1 | 1 (High) | 0 (Low) | 1 |
| | Frequency Ratio Control | | **51 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | PV Control | Application | **81 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Setting Temp Shift Value(Cooling) | **82 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | | Setting Temp Shift Value(Heating) | **83 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | Smart Grid Control | Application | **91 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Setting Temp Shift Value(Heating) | **92 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | Setting Temp Shift Value(DHW) | **93 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | DHW Mode | **94 | - | - | 0 | 0 (Standard) | 1 (Power) | 0 | 0 (Standard) | 1 (Power) |

Field Setting Value

■ FSV : Menus 502*

| | | Field Setting Value | | | | Tank integrated type | | | Wall-mounted type | | |
|---------------------|-------------------|------------------------------------|----------|------|------|----------------------|-----|---------|-------------------|-----|---------|
| Main Menu & Code | Sub Menu Function | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Others Code 50** | DHW Saving Mode | Temp Difference | **21 | 1 | °C | 5 | 0 | 40 | 5 | 0 | 40 |
| | | Saving Mode | **22 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Thermo On Temp. during Saving Mode | **23 | 1 | °C | 25 | 0 | 40 | 25 | 0 | 40 |

- 502* : DHW Saving mode

Economic DHW Heating

. DHW heating only by the heat pump to save energy.

Target DHW temperature is lower than the temperature set by user.

The temperature difference is defined by FSV #5021. (default: 5°C) If user sets the temperature 45°C, the system sets the target temperature 40°C with the default setting.

If user want additional energy saving, use a “Saving mode” (#5022, default : 0, OFF)

The user can set the “Thermo On” temperature during “Saving mode” using FSV #5023.

Field Setting Value

■ FSV : Menus 504*

- 504* : Power peak control


| Main Menu & Code | Sub Menu Function | Field Setting Value | | | Tank integrated type | | | Wall-mounted type | | | |
|---------------------|-------------------------|-----------------------------------|----------|-----------|----------------------|----------|---------|-------------------|----------|---------|-----------|
| | | Description | Sub Code | Step Unit | Default | Min | Max | Default | Min | Max | |
| Others Code 50** | Power Peak Control | Application | ** 41 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Select forced off parts | ** 42 | 1 | - | 0 (Ab) | 0 | 3 | 0 (Ab) | 0 | 3 |
| | | Using input voltage | ** 43 | - | - | 1 (High) | 0 (Low) | 1 | 1 (High) | 0 (Low) | 1 |
| | Frequency Ratio Control | Application | ** 51 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Application | ** 81 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | PV Control | Setting Temp Shift Value(Cooling) | ** 82 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | | Setting Temp Shift Value(Heating) | ** 83 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | | Application | ** 91 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | Smart Grid Control | Setting Temp Shift Value(Heating) | ** 92 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | Setting Temp Shift Value(DHW) | ** 93 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | DHW Mode | ** 94 | - | - | 0 | 0 | 1 (Power) | 0 | 0 | 1 (Power) |

Peak Power Control (FSV 5041 = 1)

- . If users make contracts with local electric power company for limiting the amount of power consumption when a surge in power usage, users can set FSV of “Forced off”.
- . And According to FSV (#5042), If input is “0 (default)”, Back up heater (BUH) is unavailable while external contact is high.
If input is “ 1”, Only Compressor(Heat Pump) is available.
If input is “ 2”, Only Booster Heater (BSH) is available.
If input is “3”, nothing is available.
- . Applying the control when power voltage of input contact is high is default. According to FSV (#5043), it is available to adopt this logic in low condition exceptionally.
- . When applying to this logic, SAMSUNG controller come to get “Thermo off” condition for all operation.

Field Setting Value

FSV : Menu 5051 (FR control)



※ ex) Normal operation
 -10°C Max Hz : 90
 0°C Max Hz : 75
 10°C Max Hz : 60

※ ex) FR 100% Control
 -10°C Max Hz : 60
 0°C Max Hz : 60
 10°C Max Hz : 60

※ ex) FR 80% Control
 -10°C Max Hz : 48
 0°C Max Hz : 48
 10°C Max Hz : 48



| Voltage (V) | FR | Hz |
|----------------|------|-----|
| 0.0 ≤ V ≤ 1.0 | 50% | min |
| 1.0 ≤ V ≤ 2.0 | 60% | |
| 2.0 ≤ V ≤ 3.0 | 70% | |
| 3.0 ≤ V ≤ 4.0 | 80% | |
| 4.0 ≤ V ≤ 5.0 | 90% | |
| 5.0 ≤ V ≤ 6.0 | 100% | |
| 6.0 ≤ V ≤ 7.0 | 110% | |
| 7.0 ≤ V ≤ 8.0 | 120% | |
| 8.0 ≤ V ≤ 8.5 | 130% | |
| 8.5 ≤ V ≤ 9.0 | 140% | |
| 9.0 ≤ V ≤ 10.0 | 150% | max |

This is to limit the maximum frequency of the outdoor unit compressor. (if #5051 = 1 "use")
 External DC signal Control uses a DC voltage of 0 ~ 10V (0v = 50%, ~ 10v = 150%)
 The minimum ~ maximum frequency section being divided with 11 steps of 10%

Field Setting Value

■ FSV : Menus 508*

- 508* : PV Control (Photovoltaics control)
- This is for energy saving by using the solar energy.
- The FSV #5081 should be set to “1(Yes)” for PV control.

| Main Menu & Code | Sub Menu Function | Field Setting Value | | | | Tank integrated type | | | Wall-mounted type | | |
|---------------------|-------------------------|-----------------------------------|----------|------|------|----------------------|---------|-----------|-------------------|---------|-----------|
| | | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Others Code 50** | Power Peak Control | Application | ** 41 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Select forced off parts | ** 42 | 1 | - | 0 (All) | 0 | 3 | 0 (All) | 0 | 3 |
| | | Using input voltage | ** 43 | - | - | 1 (High) | 0 (Low) | 1 | 1 (High) | 0 (Low) | 1 |
| | Frequency Ratio Control | Application | ** 51 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Application | ** 91 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | PV Control | Setting Temp Shift Value(Cooling) | ** 82 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | | Setting Temp Shift Value(Heating) | ** 83 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | Smart Grid Control | Application | ** 91 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Setting Temp Shift Value(Holding) | ** 92 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | Setting Temp Shift Value(DHW) | ** 93 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | DHW Mode | ** 94 | - | - | 0 | 0 | 1 (Power) | 0 | 0 | 1 (Power) |

| FSV | 0 | 1 |
|-------------|-------------------|------------|
| #5081 (New) | Disable (Default) | Activation |

* **Except for how water mode, This function is activated only for the outing mode.**

✓ **Cooling mode (FSV #5082 = 2°C, Default)**

- ① Room sensor setting : Current setting value - **FSV #5082** (Min = FSV #1022)
- ② Water outlet setting : Current setting value - **FSV #5082** (Min = FSV #1012)
- ③ Water law setting : Current setting value - **FSV #5082** (Min = FSV #2061, #2062, #2071, #2072)

✓ **Heating mode (FSV #5083 = 2°C, Default)**

- ① Room sensor setting : Current setting value + **FSV #5083** (Max = FSV #1041)
- ② Water outlet setting : Current setting value + **FSV #5083** (Max = FSV #1031)
- ③ Water law setting : Current setting value + **FSV #5083** (Max = FSV #2021, #2022, #2031, #2032)

✓ **Hot water mode**

- **Forced thermo on regardless of outing mode** : Setting temperature = Max temperature of hot water mode (FSV #1051)

Field Setting Value

■ FSV : Menus 509*

- 509* : Smart Grid Control
- The FSV #5091 should be set to “1(Yes)” for PV control.

| Main Menu & Code | Sub Menu Function | Field Setting Value | | | Tank integrated type | | | Wall-mounted type | | | |
|---------------------|-------------------------|-----------------------------------|----------|------|----------------------|----------|---------|-------------------|----------|---------|-----------|
| | | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Others Code 50** | Power Peak Control | Application | ** 41 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Select forced off parts | ** 42 | 1 | - | 0 (All) | 0 | 3 | 0 (All) | 0 | 3 |
| | | Using input voltage | ** 43 | - | - | 1 (High) | 0 (Low) | 1 | 1 (High) | 0 (Low) | 1 |
| | Frequency Ratio Control | Application | ** 51 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Application | ** 81 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Setting Temp Shift Value(Cooling) | ** 82 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | PV Control | Setting Temp Shift Value(Heating) | ** 83 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | | Application | ** 91 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Setting Temp Shift Value(Hotding) | ** 92 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | Smart Grid Control | Setting Temp Shift Value(DHW) | ** 93 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | DHWMode | ** 94 | - | - | 0 | 0 | 1 (Power) | 0 | 0 | 1 (Power) |

| FSV | 0 | 1 |
|-------------|-------------------|------------|
| #5081 (New) | Disable (Default) | Activation |

✓ Operation mode for Smart Grid

| Operation Mode | Terminal 1 | Terminal 2 |
|----------------|------------|------------|
| Mode 1 | Short | Open |
| Mode 2 | Open | Open |
| Mode 3 | Open | Short |
| Mode 4 | Short | Short |

1) **Mode 1 : Forced thermo off of all system**

2) **Mode 2 : Normal operation**

→ Normal control is performed.

(normal determination of operation ON / OFF, Thermo ON / OFF)

Field Setting Value

FSV : Menus 50**

| Main Menu & Code | Sub Menu Function | Field Setting Value | | | Tank integrated type | | | Wall-mounted type | | | |
|---------------------|-------------------------|-----------------------------------|----------|------|----------------------|----------|---------|----------------------|----------|------------|-----------|
| | | Description | Sub Code | Step | Unit | Default | Min | Max | Default | Min | Max |
| Others Code 50** | Power Peak Control | Application | ** 41 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Select forced off parts | ** 42 | 1 | - | 0 (All) | 0 | 3 | 0 (All) | 0 | 3 |
| | | Using input voltage | ** 43 | - | - | 1 (High) | 0 (Low) | 1 | 1 (High) | 0 (Low) | 1 |
| | Frequency Ratio Control | Application | ** 51 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Setting Temp Shift Value(Cooling) | ** 81 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Setting Temp Shift Value(Heating) | ** 83 | 0.5 | °C | 1 | 0 | 5 | 1 | 0 | 5 |
| | PV Control | Application | ** 91 | - | - | 0 (No) | 0 | 1 (Yes) | 0 (No) | 0 | 1 (Yes) |
| | | Setting Temp Shift Value(Heating) | ** 92 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | | Setting Temp Shift Value(DHW) | ** 93 | 0.5 | °C | 2 | 2 | 5 | 2 | 2 | 5 |
| | Smart Grid Control | DHW Mode | ** 94 | - | - | 0 | 0 | (Standard) 1 (Power) | 0 | (Standard) | 1 (Power) |

3) Mode 3 : When operating on, the setting temperature is reflected as follows (FSV #5092 = 2°C, #5093 = 5°C, Default)

→ The heating and hot water setting temperature are set by the FSV setting value.

- ① Heating mode (Room sensor setting) : Current setting value + **FSV #5092** (Max = FSV #1041)
- ② Heating mode (Water outlet setting) : Current setting value + **FSV #5092** (Max = FSV #1031)
- ③ Heating mode (Water law setting) : Current setting value + **FSV #5092** (Max = FSV #2021, #2022, #2031, #2032)
- ④ How water mode : Current setting value + **FSV #5093** (Max = FSV #1051)

4) Mdoe 4 : When operating on, the setting temperature is reflected as follows

✓ Hot water mode

- ① #5094=0 : Normal operation (Heat pump is operated.) : Target setting temperature is **55°C**.
- ② #5094=1 : Power/Forced hot water operation (Heat pump + Booster heater are operated.) : Target setting temperature is **70°C**.

✓ Heating mode


- ① Heating mode (Room sensor setting) : Current setting value + **FSV #5092 + 3°C** (Max = FSV #1041)
- ② Heating mode (Water outlet setting) : Current setting value + **FSV #5092 + 5°C** (Max = FSV #1031)
- ③ Heating mode (Water law setting) : Current setting value + **FSV #5092 + 5°C** (Max = FSV #2021, #2022, #2031, #2032)

Special mode

Self-Test mode

- Enter the self-test mode using wired remote controller,

* Load list : When pressing the corresponding button, you can set the load On or Off.



* Can set the load On or Off.

Samsung

Electronics
THANK