



<MX8600-CENL> HEATER INSTALLATION MANUAL


2018. 02. 12
R&D CENTER

1. UPPER-BODY HEATER INSTALLATION




1. OPEN THE FRONT PANEL

1-1. UPPER-BODY HEATER INSTALLATION




2. SAFETY-BODY HEATER INSTALLATION



1. OPEN THE OUT DOOR AND SAFETY DOOR.

2-1. SAFETY-BODY HEATER INSTALLATION



1. PULL OUT AND DISASSEMBLE BMD ASSY (SEE ABOVE PICTURE) FROM BMU MODULE.
2. ASSEMBLE HEATER (P/N562200009) ON BMD ASSY (SEE ABOVE PICTURE).