

ТОКАРНО- ВИНТОРЕЗНЫЙ СТАНОК (ТВ4)

Устройство



Передняя

тумба



Электродвигат

A photograph of a green metal cabinet, likely an electrical control cabinet, mounted on a wall. The cabinet has two black switches on its front panel. A power cord is plugged into the bottom switch. The cabinet is mounted on a wall, and a brown floor is visible at the bottom. The text "Задняя тумба" is overlaid in red at the top, and "Тумблеры включения станка" is overlaid in red at the bottom.

**Задняя
тумба**

**Тумблеры включения
станка**

Поддон





Станин
а


Кожух ременной
передачи






**Ременная
я
передач
а**

Гитар
а



Передняя бабка





9

10

11


12

Патрон





Коробка



Зубчатая

рейка
ВИН

ВАЛ





Суппорт



**Фартук
суппорта**



**Нижняя
каретка
Фартук
суппорта**



**Средняя
каретка
Нижняя
каретка
Фартук
суппорта**



Каретка с поворотом



Средняя



**каретка
нижняя**



каретка



**Фартук
суппорта**



Верхняя



каретка с

поворотом



Средняя



каретка
Нижняя



каретка

Фартук
суппорта

Резцедержате ль





Лампа МО

Защитный экран





Задняя бабка



Пиноль



Маховик движения пиноли



Ручка закрепления пиноли



Ручка закрепления задней
бабки



Ручка закрепления задней бабки

Вращающийся я центр



Зубчатая
рейка

