

Introduction

- X.wtool: defined the tool interface, what parameters are visible in service tool. It can support different languages.OH2 and OH6 are different.
- Support Files
 - X.sid: sid stands for Security ID number. It is used to link calibration and parameters.
 - X.dll: it is a security file.
 - Note: X.sid and X.dll files should be saved in the same folder.