

# **SECTION 8**

## **FIELDS**






# FIELDS

- **Fields (functions) allow the creation and modification of a multitude of data sets. Data fields are used in the following modeling areas:**
  - Loads and boundary conditions
  - Material properties
  - Element properties
- **Field input can either be tabular or continuous functions, with the input being scalar or vector.**
- **Complex (number) scalar fields are also permitted if the Nastran analysis preference is used.**
  - This allows, for example, real/imaginary or magnitude/phase components of a frequency dependent function to be defined.


# TYPES OF FIELDS

- There are three basic types of fields with several different input options. They are summarized as follows:
  - Spatial field
    - These fields describe data based on spatial variation. They can vary over real space, or parametric space for geometry. Spatial fields can be either scalar or vector.
  - Material property field
    - Defines a material property as a function of temperature, strain, strain-rate, time or frequency (the material state variable), or an appropriate combination of these variables.
  - Non-spatial field
    - Defines a scalar field for dynamic analysis applications. Function can vary with time, frequency, temperature, displacement, velocity, or a user-defined variable.





# BASICS OF SPATIAL FIELDS

- **Spatial fields have several parts to their definitions.**
  - The first part is the region the field will be applied to
    - The field can be used for the entire or part of the region of the model if the Real, or Discrete or Continuous option is selected, depending on the field type being




OR





# BASICS OF SPATIAL FIELDS


- If the field is being used for the region of a single geometric entity, e.g. surface, or part or all of the finite element entities, e.g. nodes, the Parametric or Discrete options are available.



OR




**Domain (application region)  
is over single surface**





**Use subset of all nodes**

# BASICS OF SPATIAL FIELDS

- The second part is the type of field being created, scalar or vector.



Thickness



**Vector Field**

# BASICS OF SPATIAL FIELDS

- The third part is the specification of the field data.

**Fields**

Fields

Action:

Object:

Method:

Field Type

☐ Scalar ☒ Vector

Coordinate System Type

☒ Real ☐ Parametric

Coordinate System

Vector Function('X', 'Y', 'Z')

First Component

Second Component

Third Component

Independent Variables

'X'  
'Y'  
'Z'

**Fields**

Fields

Action:

Object:

Method:

Field Type

☐ Scalar ☒ Vector

Coordinate System Type

☐ Real ☒ Parametric

Geometric Entity

Vector Function('C1', 'C2', 'C3')

First Component

Second Component

Third Component

Independent Variables

'C1'  
'C2'  
'C3'

**Table Definition**

Active Independent Variables

☒ X ☒ Y ☒ Z

**2D Scalar Table Data**



Input Data ☐ Auto Highlight

Data

		Y-1	Y-2
X-1	1.000000E+000	1.500000E+002	2.150000E+002
X-2	2.000000E+000	3.000000E+002	3.150000E+002
X-3	3.000000E+000	5.750000E+002	5.900000E+002
X-4	4.000000E+000	6.950000E+002	7.100000E+002
X-5			
X-6			
X-7			
X-8			


# BASICS OF SPATIAL FIELDS

- The third part is the specification of the field data.



**Thermal Results**


**FEM field**



**Stress Model LBC From Thermal Results**

# BASICS OF SPATIAL FIELDS


- **Some field types have options that allow specification of the averaging method between or beyond data points.**



- Use Closest Table Value – use table value whose independent variable value(s) is closest to that of the interpolation point
  - Linear Extrapolation – extrapolate beyond or interpolate between table entries
  - Set Value to Zero – specify data as zero beyond table entries
- **In some cases, the averaging options will have no effect. Their effect is dependent on how the field is used, and sometimes, on which finite element solver is used.**
- **Because averaging will be done, fields need to be checked for accuracy.**


# CASE STUDY 1, BOLT LOADING REPRESENTED BY COS2 FIELD

- Create a real scalar field to represent a cos2 bolt loading.



# CASE STUDY 1, GOAL


- The goal is to conduct a preliminary design study of a wing-to-body 3D fitting. Due to the high loads and close (very similar) dimensions, careful attention to the loading conditions must be considered even for the initial study.
- To make the loading condition more realistic, a loading distribution of cosine squared ( $\cos^2 q$ ) is used.



- To make the pressure loading application region more realistic, the direction in which the load from the pin acts will also be considered.

# CASE STUDY 1, APPROACH TO APPLYING LOAD


- **Approach to creating the analysis model:**
  - Create a 3D geometry model for the 3D fitting.
    - The model is taken to be symmetric about a vertical plane (\*), between the pin hole pairs, that divides the fitting into two pieces:



# CASE STUDY 1, APPROACH TO APPLYING LOAD

- **Approach to creating the analysis model**



- The applied loads are obtained from a free-body analysis of a beam element model of the main spars.



- The loads for the two halves of the model will be taken to be equal (loads are symmetric about the vertical plane).
- The applied concentrated forces will have to be represented by pressure.
  - Pressure will be obtained by integrating a pressure field, in the direction of loading, over an application area.
- The pressure field will be applied to solid geometry faces


# CASE STUDY 1, CONSTRAINT (REACTION) FORCES

- From the full aircraft model, a beam element representation of the main spars is made and analyzed.
- The free-body forces (\*) will be used to determine the pressure loading. (Both halves of the wing-to-body fitting are represented here.)
- The components of these forces (\*\*) will be used to establish the required direction of the pressure loading.



# CASE STUDY 1, CREATE PRESSURE FROM FORCE

- The force (both symmetric halves of the fitting are included) at the top (\*) and bottom (\*\*) bolts is 25,600 lbf and 26,600 lbf, respectively.
- To determine the constant amplitude of the cosine squared function,  $p_0$ , it is necessary to integrate the pressure function over the area the pressure is to be applied to; it is the component of the applied pressure function in the direction of the applied force that is to be integrated.



# CASE STUDY 1, CREATE PRESSURE FROM FORCE

- Integrating the component of the pressure function,  $p = p_0 \cos^2(\theta + \pi/2)$ , in the direction of the applied load, the following is found:

$$f = \int_0^{\pi} p_0 \cos^2(\theta + \pi/2) \sin(\theta) R t d\theta = \frac{4}{3} p_0 R t$$

where  $R$  is the radius of the bolt hole, and  $t$  is the thickness of the clevis.

- Solve for  $p_0$  in terms of the applied concentrated load

$$p_0 = \frac{3f}{4Rt} = \frac{3f}{2Dt}$$


- Applying this formula to one of the applied forces, the following is found:

$$p_0 = \frac{3f}{2Dt} = \frac{3 * 25600}{2 * 1.501 * (2 * 0.980)} = 13052.5 \text{ psi}$$

where  $D = 1.501$  in and  $t = 0.980$  in.; multiply  $t$  by 2 for symmetry.

# CASE STUDY 1, ESTABLISHING THE LOAD APPLICATION AREA

- **Create coordinate systems at the center of the bolt holes to do the following:**
  - Specify the direction of the loading.
  - Break the geometry to create solid faces the loading will be applied to.
  - Use the coordinate systems to provide variables for the creation of the fields for the loading.
- **On the symmetry model, create a cylindrical coordinate system at the center of each hole.**




# CASE STUDY 1, ESTABLISHING THE LOAD APPLICATION AREA

- Calculate the angle to rotate the coordinate frames. This will be based on the components of the free-body force.

$$\theta_{\text{top}} = \text{Tan-1}( -2,480 \text{ lbf} / -25,500 \text{ lbf} ) \\ = 5.56 + 180 \text{ degrees}$$

$$\theta_{\text{bottom}} = \text{Tan-1}( -2,480 \text{ lbf} / 26,400 \text{ lbf} ) = -5.37 \text{ degrees}$$



- The previously created coordinate frame at the center of the holes is used to create the rotated frames.
  - The original coordinate frames were deleted.



# CASE STUDY 1, ESTABLISHING THE LOAD APPLICATION AREA

- **Break the solid using the rotated coordinate frames. This gives the needed solid faces for applying the pressure.**
  - In Geometry: Edit/Solid/Break, Option: Plane, use the second (theta) direction from the picking filter and the hole center coordinate frame to break the solid.




Shown only for clarity, the broken pieces of the solid are displayed after being translated away from the original solid.



# CASE STUDY 1, MESH THE SOLIDS

- **TetMesh the model**

- Use mesh seeds for a finer mesh around the pin holes.
- Mesh the 3 solids simultaneously.
- Equivalence the model to connect the tets at the geometric interfaces.



# CASE STUDY 1, CREATE THE FIELD

- A separate field and pressure load set needs to be created for each pin hole loading.
- Create the field for the top pin hole.
  - As the field will be used for pressure loading, Field Type must be **Scalar**.
  - Coordinate System Type is set as **Real** and Coordinate System is the cylindrical coordinate system, created by rotating about the center of the hole, **Coord 18**.

The screenshot shows the 'Fields' dialog box with the following settings:

- Action:** Create
- Object:** Spatial
- Method:** PCL Function
- Existing Fields:** (Empty list)
- Field Name:** top\_pin
- Field Type:** ☒ Scalar ☐ Vector
- Coordinate System Type:** ☒ Real ☐ Parametric
- Coordinate System:** Coord 18
- Scalar Function:**  $(\cos(r('T + 3.14159/2)))^2$
- Independent Variables:** R, T, Z
- Buttons:** Create Variable ..., -Apply-

# CASE STUDY 1, CREATE THE FIELD


- **Scalar Function in the form has 4 key components:**
- **$\cosr('T+3.14159/2))^{**2}$**

<b>cosr</b>	<b>This specifies that the argument of cosine is in radians.</b>
<b>'T'</b>	<b>Taken from the Independent Variables list, this is the spatial variable based on the coordinate system selected. The coordinate systems created in Patran are in radians.</b>
<b>3.14159/2</b>	<b>This value is used to rotate the field a quarter turn or 90 degrees.</b>
<b>**2</b>	<b>This is the exponential or squared term of <math>\cos^2</math>.</b>

The screenshot shows the 'Fields' dialog box in Patran. The 'Action' is set to 'Create', the 'Object' is 'Spatial', and the 'Method' is 'PCL Function'. The 'Existing Fields' list is empty. The 'Field Name' is 'top\_pin'. The 'Field Type' is 'Scalar'. The 'Coordinate System Type' is 'Real', and the 'Coordinate System' is 'Coord 18'. The 'Scalar Function' is '(cosr('T + 3.14159/2))\*\*2'. The 'Independent Variables' list contains 'R', 'T', and 'Z'. The 'Create Variable ...' button is visible, along with an '-Apply-' button at the bottom.

# CASE STUDY 1, VERIFY CREATED FIELD

- Verify the created field.
- In Fields: Show, Specify Range gives a range over which the field acts and the number of points for the display.
  - In this case, only the loaded side of the hole is specified, 0 radians to 3.142 radians with 9 divisions.



**Specify Range**

Independent Variable Range

	Minimum	Maximum	No. of Points
T	0.0	3.142	9

OK

**Plotted Curves**

T	Value
0.	0.00011655738
0.39274999	0.13893066
0.78549999	0.4893063
1.17825	0.84594756
1.571	0.99988782
1.96375	0.86092854
2.3564999	0.51049018
2.7492499	0.15390535
3.142	0.00010793401

Action: Show ▼

Select Field To Show

bottom\_pin  
top\_pin

Select Independent Variable

☒ T

Specify Range...


☒ Post XY Plot

Unpost Current XYWindow

Apply

# CASE STUDY 1, VERIFY CREATED FIELD

- If the plot or table data does not look correct, increase the number of points.
  - Sometimes, confusion over degrees or radians can arise, that can be hidden by using too few points.
  - The Plot below shows a much smoother curve than before; the coarser curve could be representative of several superimposed functions.





A dialog box titled "Specify Range" with a blue title bar. It contains a section labeled "Independent Variable Range" with three input fields: "Minimum" (0.0), "Maximum" (3.142), and "No. of Points" (19). The "No. of Points" field is highlighted with a red box. An "OK" button is at the bottom.

A vertical panel with a grey background. At the top is an "Action:" label with a "Show" dropdown menu. Below is a "Select Field To Show" section with a list box containing "bottom\_pin" and "top\_pin", where "top\_pin" is selected. Underneath is a "Select Independent Variable" section with a radio button selected for "T" and a "Specify Range..." button. Further down is a checkbox labeled "Post XY Plot" which is checked. Below that is an "Unpost Current XYWindow" button. At the very bottom is an "Apply" button.



# CASE STUDY 1, CREATE THE PRESSURE LOAD

- **Create the load for the top pin.**
  - Target Element Type is 3D because solid finite elements are used.
  - In the Input Data form, the Load/BC Set Scale Factor is set to 13,052.5 psi.
  - The Pressure input is field top\_pin.



# CASE STUDY 1, CREATE THE PRESSURE LOAD



- The application region form is set to Geometry and the solid face representing the pin contact area is selected.



# CASE STUDY 1, DISPLAYING THE PRESSURE LOAD





- **Display / Load/BC/Elem. Props...** is used to view the pressures on the finite elements.
  - For clarity, only some of the elements and their pressures are shown.
- Notice that the pressures correctly approach zero at the ends, and are close to the value of 13,052.5 psi near the center.



# CASE STUDY 1: RUNNING THE ANALYSIS


- The image of the finite element model (to the left) displays the pressure markers at the two holes.
- The fringe plot to the right shows stress tensor results:






# CASE STUDY 2, SPATIAL/PCL FUNCTION FIELDS, PARAMETRIC

- Model a submarine stiffening ring that has varying cross-sectional dimensions, using beam elements.
- The top of the ring has a constant cross-section (A-A), and the bottom cross-section varies from A-A to B-B to A-A.
- Use Fields: Create / Spatial / PCL Function



## CASE STUDY 2, CREATE GEOMETRY

- First, create geometric curves that represent the ring. When meshed with beam elements, they have either constant or varying cross-sectional properties.
- The top curves (Curve 1, 2) are for elements with constant cross-sectional properties, and the bottom curves are for varying properties.
- For this case study, create the model just for Curve 3.



## CASE STUDY 2, CREATE THE FIELD

- It is necessary to create two spatially varying fields, one for the height of the cross-section, and the other for the width of the cross-section.
- Use Parametric for Coordinate System Type.

The image displays two side-by-side screenshots of the 'Fields' dialog box in a software application. Both dialog boxes are configured for creating a new field.

**Left Dialog Box:**





- Action:** Create
- Object:** Spatial
- Method:** PCL Function
- Existing Fields:** (Empty list)
- Field Name:** height\_taper
- Field Type:** ☒ Scalar ☐ Vector
- Coordinate System Type:** ☐ Real ☒ Parametric
- Geometric Entity:** Curve 3
- Scalar Function:**  $15.0 + 15.0 * C1$
- Independent Variables:** 'C1, 'C2, 'C3
- Create Variable ...** (Button)

**Right Dialog Box:**

- Action:** Create
- Object:** Spatial
- Method:** PCL Function
- Existing Fields:** height\_taper
- Field Name:** width\_taper
- Field Type:** ☒ Scalar ☐ Vector
- Coordinate System Type:** ☐ Real ☒ Parametric
- Geometric Entity:** Curve 3
- Scalar Function:**  $12.0 + 12.0 * C1$
- Independent Variables:** 'C1, 'C2, 'C3
- Create Variable ...** (Button)

# CASE STUDY 2, CREATE PROPERTIES USING THE FIELDS




- In Properties, the dimensions of the “I” beam are specified using Beam Library.
- The appropriate fields (e.g. height\_taper) are used from the Spatial Scalar Fields menu.



# CASE STUDY 2, VERIFY THE BEAM CROSS-SECTION PROPERTIES



- Use Display: Load/BC/Elem. Props, Beam Display to view the finished beam cross-sections in the viewport.



# FIELDS

## SPATIAL/PCL FUNCTION, VECTOR

- **Spatial/PCL Function, Vector** is similar to Scalar except that individual direction components can be specified:
  - Using Real for Coordinate System Type will make the independent variables relative to the coordinate system chosen.
  - Using Parametric for Coordinate System Type will make the independent variables relative to the geometric entity parametric coordinate system.



The image displays two identical screenshots of the 'Fields' dialog box, arranged side-by-side. The dialog box is titled 'Fields' and contains the following sections:

- Action:** A dropdown menu set to 'Create'.
- Object:** A dropdown menu set to 'Spatial'.
- Method:** A dropdown menu set to 'PCL Function'.
- Existing Fields:** A list box with a '+' icon and a scroll bar, currently empty.
- Field Name:** A text input field.
- Field Type:** Radio buttons for 'Scalar' and 'Vector'. The 'Vector' option is selected.
- Coordinate System Type:** Radio buttons for 'Real' and 'Parametric'. The 'Parametric' option is selected.
- Coordinate System:** A text input field containing 'Coord 0'.
- Vector Function('X', 'Y', 'Z'):** A section with three text input fields for 'First Component', 'Second Component', and 'Third Component', all of which are empty.
- Independent Variables:** A list box with a '+' icon and a scroll bar, containing the text 'X', 'Y', and 'Z'.
- Apply-** A button at the bottom right.

The second screenshot on the right shows the same dialog box but with the 'Coordinate System Type' set to 'Real' and the 'Independent Variables' list box containing 'C1', 'C2', and 'C3'.


## CASE STUDY 3, VARYING TRACTION LOAD ON A SPIKE

- Use Spatial/PCL Function to make a vector field, representing a varying traction load and radial-pressure load on a spike.



## CASE STUDY 3, VARYING LOAD


- The traction load from tip to base varies linearly from 12 to 9 over the 6 unit length of the spike.
- The radial-pressure load starts at 0 and decreases exponentially to -16 at the base.



- The chart and equations describe the individual components for the vectors.
  - $F_p$  is the radial-pressure and  $F_t$  is the traction load.

# CASE STUDY 3, CREATE THE FIELD

- **Spatial/PCL Function, Vector references the cylindrical coordinate system at the tip of the spike, Coord 1.**
  - With reference to a cylindrical coordinate system, the first component will be applied only in the radial direction, R, and the third component will be applied only in the axial direction, Z.
- **In both equations, the distance along the spike from the tip, Z, is the independent variable.**



LBC/Elem. Prop. Attributes

Fields

Action: Create

Object: Spatial

Method: PCL Function

Existing Fields

Pressure\_variation

Field Name

Pressure\_variation

Field Type

☐ Scalar ☒ Vector

Coordinate System Type

☒ Real ☐ Parametric

Coordinate System

Coord 1

Vector Function('X', 'Y', 'Z')

First Component

$-(2*Z/3)**2$

Second Component

Third Component

$(12-Z/2)$



Independent Variables

'R'  
'T'  
'Z'

-Apply-


# CASE STUDY 3, CHECK THE FIELD

- **Use Fields/Show to check the equation.**
  - In the Select Independent Variable, only the Z variable is shown, as it is the only variable used in the equations.
  - Specify the range of the equations as the model length. The range is from 0 to 6 units with 7 divisions.



# CASE STUDY 3, CHECK THE FIELD

- Only one component of the vector function can be plotted and tabulated at a time.
- The first direction, radial, component is shown.
  - Note the negative values and exponential trend.



Z	Value
0.	0.
1.	-0.44444448
2.	-1.7777779
3.	-4.
4.	-7.1111116
5.	-11.111111
6.	-16.

Fields

Action:

Select Field To Show

Pressure\_variation

Select Independent Variable

☒ Z


Select Vector Component

☒ 1 ☐ 2 ☐ 3

☒ Post XY Plot

# CASE STUDY 3, CHECK THE FIELD

- The third direction, axial, component is now plotted.
  - Note the positive values and negative linear trend.



Z	Value
0.	12.
1.	11.5
2.	11.
3.	10.5
4.	10.
5.	9.5
6.	9.

**Fields**

Action: Show

Select Field To Show  
Pressure\_variation

Select Independent Variable  
☒ Z  
Specify Range...

Select Vector Component  
☐ 1 ☐ 2 ☒ 3

☒ Post XY Plot



Unpost Current XYWindow

Delete All Curves

Apply



## CASE STUDY 3, CHECK THE FIELD

- To load the spike, use **CID Distributed Load**.
  - The load is applied to shell elements so the **Target Element Type** is 2D.
- From the **Input Data** form, select the spatial field previously created.
  - No scale factor is needed, so the **Load/BC Set Scale Factor** is left as the default value 1.
- For the analysis coordinate frame, select the cylindrical coordinate system at the tip of the model.





# CASE STUDY 3, CHECK THE FIELD

- For the Select Application Region, select all the shell elements used to model the spike



## CASE STUDY 3, CHECK THE FIELD

- Display of the varying load on the elements:






# FIELDS, SPATIAL/TABULAR INPUT, REAL

- **Spatial/Tabular Input, Real**

- Real for Coordinate System Type uses the specified coordinate system.
- The Independent Variables chosen will affect the layout of table input form.
- If all 3 directions are chosen, the Z direction will be specified using table layers.
- Import/Export



3D Scalar Table Data


Input Data ☐ Auto Highlight Import/Export...

Data

	Y-1	Y-2
X-1		
X-2		
X-3		
X-4		
X-5		
X-6		
Y-7		

Layer: 1 Z

OK Undo



Fields

Action: Create

Object: Spatial

Method: Tabular Input

Existing Fields

height\_taper  
width\_taper

Field Name

Coordinate System Type

☒ Real ☐ Parametric

Coordinate System Coord 0

Table Definition

Active Independent Variables



☒ X ☒ Y ☒ Z

Input Data ...

[Options...]


# FIELDS, SPATIAL/TABULAR INPUT, PARAMETRIC

- **Spatial/Tabular Input, Parametric, Endpoints Only:**  
**no**
  - The Parametric selection will make the tabular data relative to the chosen Geometric Entity parametric coordinate system.
  - Input Data will be controlled in the same fashion as the Coordinate System Type set to Real.
  - Import/Export




# FIELDS, SPATIAL/TABULAR INPUT, PARAMETRIC

- **Spatial/Tabular Input, Parametric, Endpoints Only: yes**
  - Enabling Endpoints Only (yes) limits the input data to only the corners of the Geometric Entity selected.
  - Linear interpolation across the parametric space will occur between the corners.



# FIELDS, SPATIAL/TABULAR INPUT, PARAMETRIC

- **Spatial/Tabular Input, Parametric, Endpoints Only: yes**
- **The selected Active Independent Variables will determine what data can be input.**
  - The Input Data form will reflect the variables selected.
  - Input Data allows the input of data at the specified corners of the Geometric Entity selected.



**Linear Parametric Table**

Fields | Linear Parametric Table

Endpoint Values (C1,C2,C3)	Value
(0,0,0)	
(0,0,1)	
(0,1,0)	
(0,1,1)	
(1,0,0)	
(1,0,1)	
(1,1,0)	
(1,1,1)	

OK Cancel

**Fields**

Fields

Action: Create

Object: Spatial

Method: Tabular Input

Existing Fields

Field Name

Coordinate System Type

☐ Real ☒ Parametric

Geometric Entity

Solid 1

Table Definition

Active Independent Variables

☐ 1D ☐ 2D ☒ 3D




Input Data ...

[Options...]

☒ Endpoints Only

# FIELDS, SPATIAL/TABULAR INPUT, OPTIONS


- **Spatial/Tabular Input, [Options]**
  - The top portion of the Tabular Input, [Options] controls how many data points for each direction will be available in the tabular input.
  - Extrapolation Option allows the selection of the following:
    - Use Closest Table Value
    - Linear Extrapolation
    - Set Value to Zero
  - Incomplete Data Action allows the selection not having adequate data will be dealt





## CASE STUDY 4, RADIATION TO TUBES


- A high temperature heat exchanger is radiating to thin tubes that are close to it. From the given data, make a Tabular Field for estimating the temperature distribution of the tubes.



# CASE STUDY 4, TEMPERATURE VERSUS DISTANCE


- The effect of the heat exchanger's radiation is approximated by the temperature distribution graph and table below.
  - Create a Tabular Field from the data using linear interpolation between data points.

Distance(radial) from center of exchanger	Distance along heat exchanger	
	0	10
2	500 °F	360 °F
3	450 °F	300 °F
6	120 °F	120 °F




# CASE STUDY 4, FIELD: SPATIAL/TABULAR INPUT

- Use Real for the Spatial/Tabular Input Coordinate System Type, and reference the cylindrical coordinate system at the base of the heat exchanger.
  - By choosing a cylindrical coordinate system, the **Active Independent Variables** change from X Y Z to R T Z.
- From the given data, temperature variations will only vary as a function of radius and distance along the exchanger. For this reason, only R and Z are picked for the Active Independent Variables.

The image shows a screenshot of the 'Fields' dialog box in MSC Software. The 'Fields' tab is active. Under 'Action', 'Create' is selected. Under 'Object', 'Spatial' is selected. Under 'Method', 'Tabular Input' is selected. In the 'Existing Fields' list, 'Temp\_Field' is listed. The 'Field Name' is 'Temp\_Field'. Under 'Coordinate System Type', 'Real' is selected (indicated by a green dot) and 'Parametric' is unselected. Under 'Coordinate System', 'Coord 1' is selected. Under 'Table Definition', 'Active Independent Variables', 'R' and 'Z' are checked (indicated by green checkmarks), while 'T' is unchecked. Buttons for 'Input Data...', '[Options...]', and '-Apply-' are visible at the bottom.


# CASE STUDY 4, FIELD: SPATIAL/TABULAR INPUT

- **Input Data provides a 2 dimensional table with independent variables, R and Z.**
  - The radii are in the “R” column (rows 1,2,3), and the distances along exchanger are in the “Z” row (column 1,2).
- **Under [Options], Extrapolation Option should be set to Linear Extrapolation.**
  - In this case, the option could be ignored, as Nastran will only make a linear extrapolation from one point to another.




The '2D Scalar Table Data' dialog box shows a table with 3 columns: 'R', 'Z-1', and 'Z-2'. The 'R' column has 8 rows (R-1 to R-8). The 'Z-1' and 'Z-2' columns have 3 rows (Z-1, Z-2, Z-3). The table contains numerical data in scientific notation.

		Z-1	Z-2
		0.000000E+000	1.000000E+001
R-1	2.000000E+000	5.000000E+002	3.600000E+002
R-2	3.000000E+000	4.500000E+002	3.000000E+002
R-3	6.000000E+000	1.200000E+002	1.200000E+002
R-4			
R-5			
R-6			
R-7			
R-8			




# CASE STUDY 4, FIELD: SPATIAL/TABULAR INPUT

- **Verify the field by using Show.**
  - Under **Select Independent Variable**, only one direction can be chosen. The chosen variable will become the Independent Variable in the form under **Specify Range**.
  - The **Specify Range** form generally appears filled in with the range and number of points taken from the input. This can, of course, be changed manually, or if no values appear, try checking **Use Existing Points**.






The 'Specify Range' dialog box is shown. It has a title bar with standard window controls. Inside, there is a checkbox labeled 'Use Existing Points' which is currently unchecked. Below this, there are two sections for specifying ranges. The first section, 'Independent Variable Range', has a label 'R' and three input fields: 'Minimum' (2.0), 'Maximum' (6.0), and 'No. of Points' (3). The second section, 'Fixed Independent Variable Range', has a label 'Z' and three input fields: 'Minimum' (0.0), 'Maximum' (10.0), and 'No. of Sets' (2). At the bottom center is an 'OK' button.



The 'Fields' dialog box is shown. It has a title bar with standard window controls. Inside, there is a tab labeled 'Fields'. Below the tab, there is an 'Action:' label and a 'Show' button. Below that, there is a 'Select Field To Show' section with a list box containing 'Temp\_Field'. Below the list box, there is a 'Select Independent Variable' section with two radio buttons: 'R' (selected) and 'Z'. Below the radio buttons is a 'Specify Range...' button. At the bottom, there is a checkbox labeled 'Post XY Plot' which is checked. Below the checkbox are three buttons: 'Unpost Current XYWindow', 'Delete All Curves', and 'Apply'.


# CASE STUDY 4, SHOW FIELD

- The plot shows the temperature gradient in the radial direction. There is a curve for each end of the exchanger,  $Z = 0$  or  $10$ .




## CASE STUDY 4, TEMPERATURE LBC USING FIELD

- Using the field to create a temperature LBC for the thin tubes produces the following temperature distribution
- There may be a problem with this temperature distribution




## CASE STUDY 4, TEMPERATURE LBC USING FIELD

- The maximum temperature is 541 degrees, which is  $>$  maximum temperature specified in the field, 500 degrees.
- It may be desired to limit the temperature created using the table.



# CASE STUDY 4, ADD DATA TO FIELD DEFINITION

- To limit the field temperature, a decrease in temperature to the ambient 120 degrees is added to the field.
  - The extra data points will establish a zero temperature gradient for the remainder of the model.
    - Note that the distance -2.0 or 12.0 establish the drop in temperature, while -2.1 and 12.1 with identical temperature values establish the zero gradient.



Distance (radial) from center of exchanger	Distance along heat exchanger					
	-2.1	-2.0	0.0	10.0	12.0	12.1
2	120 °F	120 °F	500 °F	360 °F	120 °F	120 °F
3	120 °F	120 °F	450 °F	300 °F	120 °F	120 °F
6	120 °F	120 °F	120 °F	120 °F	120 °F	120 °F

# CASE STUDY 4, ADD DATA TO FIELD DEFINITION

- **Modify the field, Temp\_Field.**
  - Add the additional columns of data from the previous slide.

2D Scalar Table Data

Input Data ☐ Auto Highlight Import/Export...

Data

	R	1	2
Z		-2.0999999E+000	-2.0000000E+000
1	2.0000000E+000	1.2000000E+002	1.2000000E+002
2	3.0000000E+000	1.2000000E+002	1.2000000E+002
3	6.0000000E+000	1.2000000E+002	1.2000000E+002
4			
5			
6			
7			
8			

**Fields**

Action: Modify

Object: Spatial

Method: Tabular Input

Select Field To Modify

Temp\_Field

Rename Field as

Temp\_Field

Coordinate System Type

☒ Real ☐ Parametric

Coordinate System

Coord 1

Table Definition

☐ Time Independent Variables

☐ T ☒ Z

Input Data ...


[Options...]

Data

	1	2	3	4	5	6
Z	-2.0999999E+000	-2.0000000E+000	0.0000000E+000	1.0000000E+001	1.2000000E+001	1.2100000E+001
1	1.2000000E+002	1.2000000E+002	5.0000000E+002	3.6000000E+002	1.2000000E+002	1.2000000E+002
2	1.2000000E+002	1.2000000E+002	4.5000000E+002	3.0000000E+002	1.2000000E+002	1.2000000E+002
3	1.2000000E+002	1.2000000E+002	1.2000000E+002	1.2000000E+002	1.2000000E+002	1.2000000E+002

# CASE STUDY 4, TEMPERATURE LBC USING FIELD MODIFIED

- The temperature distribution from the modified field, is shown below. The ends of the thin tubes are at or approaching 120 degrees.





# FIELDS, SPATIAL/FEM, DISCRETE

- **Spatial/FEM, Discrete is used to create a field for a part of a finite element model.**
  - Field Type can be either Scalar or Vector.
  - Entity Type can be either on Node or Element.
- **The Input Data form is used to input data (Values) corresponding to either nodes or elements.**
  - If the data is scalar, the value is a real scalar number, e.g. 10.5.
  - If the data is vector, the value is a vector, e.g. <x y z>.

**Discrete FEM Field Table Data**

☐ Auto Highlight

Input Data Import/Export

	Entity	Values
1	Node 1	10.
2	Node 2	20.
3	Node 3	30.
4		
5		
6		
7		
8		
9		

Delete selected row(s)

Clear selected cells

Number of rows to Insert:

Insert row(s)

OK Undo

**Forms**

Fields

Action: Create

Object: Spatial

Method: FEM

Existing Fields

Field Name:

FEM Field Definition

☒ Discrete ☐ Continuous

Field Type

☒ Scalar ☐ Vector


Entity Type

☒ Node ☐ Element

Input Data ...




# FIELDS, SPATIAL/FEM, CONTINUOUS

- This is a useful tool for transferring displayed results (e.g. temperature distribution) to a Load/BC or element property.
- **Spatial/FEM, Continuous** is used to create a field based on an existing (displayed) scalar or vector plot for a finite element model.
  - The plot must be displayed in a viewport.
- **Mesh/Results Group Filter** allows different selections for the field by
  - individual group
  - multiple groups through selection
  - what is currently in the viewport



# FIELDS, SPATIAL/FEM, CONTINUOUS, OPTIONS


- **Extrapolation Option** provides the extrapolation methods that the other field types have.
- **Using 2D to 3D Interpolation** will project a 2D field into 3D space, as defined by the **Axis Normal to Interp. Plane** and the **Coordinate System** chosen.
  - This is particularly valuable when the FEM field created will be applied to an entity that does not exactly match the original shells.
  - Additionally, an FEM field created from a 2D shell model could be applied to a 3D solid element model.






# CASE STUDY 5, MODIFICATION OF MASS THROUGH FIELDS

- A cargo container ship must be analyzed with many different loads and loading/weight distributions.
- Use Patran Fields to manage and modify a number of masses that are used to represent the different loads.



## CASE STUDY 5, DESCRIPTION


- The different potential loads for a cargo ship are represented by Nastran CONM2s connected to the structure with RBE2s.



- Patran has a special feature for importing model files with multiple point masses. The masses are consolidated into a single field used in a single property.
- These individual masses, for the field, can then be displayed and modified in a single table.


# CASE STUDY 5, CREATING POINT MASSES

- In this case study, the point masses are first created in Patran Properties: Create / 0D / Mass
- Three property sets; mass100, mass120, and mass135; each with its mass, e.g. 135.0 for property set mass135, and corresponding application region of three points (see the figure in the previous slide), are created.




# CASE STUDY 5, MODIFICATION OF THE MASS FIELD

- **Export a solver file (e.g. .DAT), then import the file.**
- **A new mass property set named conm2 is created.**
- **Properties: Modify shows that the new mass set, conm2, references the field f:conm2.Mass.**



# CASE STUDY 5, MODIFICATION OF THE MASS FIELD

- **Fields: Modify, and select Spatial. Select the field conm2.Mass.**
- **Select Input Data. The table consists of element IDs and corresponding 0D mass values.**




Discrete FEM Field Table Data

☒ Auto Highlight

Input Data Import/Export...

	Entity	Values
1	Elem 1	100.
2	Elem 2	120.
3	Elem 3	120.
4	Elem 4	135.
5	Elem 5	135.
6	Elem 6	100.
7	Elem 7	100.
8	Elem 8	120.
9	Elem 99	135.



Fields

Fields

Action: Modify

Object: Spatial

Method: FEM

Select Field To Modify

conm2\_Mass

Rename Field as

conm2\_Mass

FEM Field Definition:

Discrete

Field Type:

Scalar



Entity Type

☐ Node ☒ Element

Input Data ...


# CASE STUDY 5, MODIFICATION OF THE MASS FIELD

- Click on a particular Values cell (mass). The value will be displayed in the Input Data box.
  - An Entity or Values entry can be changed once selected.
- After changing the value, press the Enter key to write the value to the cell.
  - After changing the data, click the Apply button on the main Fields form. This will update the field.



# CASE STUDY 5, MODIFICATION OF THE MASS FIELD

- The original mass properties and modified mass properties are shown below:




## CASE STUDY 5, ALTERNATE METHOD

- For this case study, individual properties (e.g. mass135, mass=135, Point 266, 291, 293) were first created, then the fields representing these properties were created as a result of exporting then importing a solver model file (e.g. .DAT). Another option would have been to make the field for the masses directly in Patran. Either approach would work.


# **CASE STUDY 6**

## **FEM FIELD, CONTINUOUS CFD PRESSURE TO PATRAN PRESSURE**

# CASE STUDY 6, APPLYING CFD PRESSURE DATA FEM FIELD, CONTINUOUS



Imported CFD pressure data as  
Patran temperature contour



Patran pressure contour for  
structural model

# CASE STUDY 6, FEM FIELD, CONTINUOUS

- **This case study demonstrates the use of FEM Field, Continuous as a way of creating an LBC for a structural model from results for a different type of model (e.g. a CFD model).**
- **This case study demonstrates one way to get CFD pressure data into Patran.**
- **The method shown is for CFD data in the form of point locations and corresponding pressures.**
- **An attempt will be made to explain problems with this approach and discuss alternatives. There are other approaches for getting the data into Patran.**

# CASE STUDY 6, CFD PRESSURE DATA

- **Given**

- Table of position (x,y,z) and corresponding pressure data.
- Model is of an Eppler 205 airfoil consisting of 3 rib type section of data.

- **Example of given data:**


x	y	z	pressure
1.00000	.00000	.0000	-0.2072
0.97050	.00000	.0043	-0.4144
0.92290	.00000	.0120	-1.1037
0.85620	.00000	.0220	-1.8829
0.77410	.00000	.0342	-2.6467
0.68110	.00000	.0478	-3.2535
0.58220	.00000	.0615	-3.5787
0.48270	.00000	.0734	-3.5436

# CASE STUDY 6, PATRAN IMPORT METHODS

- **The most practical way to import this form of data is to put it in the form of Nastran input records (bulk data).**
  - This could be accomplished in a number of ways:
    - A script could be created that reads the data, then writes it in the format needed for Nastran (bulk data)
    - The text information could be brought into another program such as Microsoft Excel for manipulation into Nastran input record format.
    - A modification or adjustment to the CFD code could possibly produce Nastran records.
  - Once the data is in the form of an Nastran input file, it can be imported into Patran using File/Import/Nastran Input.
- **Other approaches include the use of**
  - Patran neutral and results files
  - ABAQUS input file, .inp file (text file)
  - ANSYS input file (text file)

## CASE STUDY 6, CREATE NASTRAN INPUT FILE

- In this example, Microsoft Excel is used. Below, is a screen snap-shot of the raw data brought in from the text file.




	A	B	C	D
1	x	y	z	pressure
2	1.0000	0.0000	0.0000	-0.2072
3	0.9705	0.0000	0.0043	-0.4144
4	0.9229	0.0000	0.0120	-1.1037
5	0.8562	0.0000	0.0220	-1.8829
6	0.7741	0.0000	0.0342	-2.6467
7	0.6811	0.0000	0.0478	-3.2535
8	0.5822	0.0000	0.0615	-3.5787

- The Excel file data is divided into three sheets. The first one (shown) contains the raw data.

# CASE STUDY 6, CREATE NASTRAN INPUT FILE


- **Second sheet**
  - Location (x,y,z) data



The screenshot shows a spreadsheet titled 'Eppiler205.txt' with columns A through F. The data is as follows:

	A	B	C	D	E	F
1						
2	GRID	1	0	1.00000	0.00000	0.00000
3	GRID	2	0	0.97049	0.00000	0.00427
4	GRID	3	0	0.92285	0.00000	0.01196
5	GRID	4	0	0.85624	0.00000	0.02199
6	GRID	5	0	0.77412	0.00000	0.03419
7	GRID	6	0	0.68108	0.00000	0.04777
8	GRID	7	0	0.58218	0.00000	0.06147

- **Third sheet**
  - Pressure data




The screenshot shows a spreadsheet titled 'Eppiler205.txt' with columns A through E. The data is as follows:

	A	B	C	D	E
1					
2	TEMP	1	1	-0.20720	
3	TEMP	1	2	-0.41440	
4	TEMP	1	3	-1.10373	
5	TEMP	1	4	-1.88287	
6	TEMP	1	5	-2.64672	
7	TEMP	1	6	-3.25352	
8	TEMP	1	7	-3.57866	

# CASE STUDY 6, CREATE NASTRAN INPUT FILE

- Once the data is arranged, write it to a text file(s).
- Once the text file(s) is created, it can be imported into Patran.





# CASE STUDY 6, VERIFY IMPORTED NASTRAN INPUT FILE DATA

- Imported Nastran grid points, called Patran nodes.



# CASE STUDY 6, VERIFY IMPORTED NASTRAN INPUT FILE DATA

- Under Loads/BCs, the temperature should be plotted to make sure the data is correct.
  - If Tempe\_temp.1 is not listed under Assigned Load/BC Sets, go to Case Control. Make sure the load is assigned to a load case.



# CASE STUDY 6


## TEMPERATURE TO PRESSURE IN PATRAN

- **Use the temperature information in Patran to create pressure for a structural model. This is done using a continuous FEM Field. Once the field is created, it can then be used to create a Loads/BCs pressure set.**

# CASE STUDY 6

## GENERAL ISSUES FOR CONTINUOUS FEM FIELDS

- **There are several issues that may have to be dealt with in creating continuous FEM Fields**
  - One issue is that if the domain/region for the creation of the FEM Field is not exactly (within tolerance) where the field is to be applied, then, when the field is used averaging (interpolating/extrapolating) must be performed. The effects of the averaging are not always known. The averaging Options may help to improve the quality of averaging. Sometimes, values obtained by the FEM Field, outside of the domain used for creating it, are of poor quality.



# CASE STUDY 6, GENERAL ISSUES FOR CONTINUOUS FEM FIELDS

- (Continued) This issue can be partially resolved for 2D models by enabling an Option to extend the field in one of three coordinate directions. Effectively, this maps 2D data to 3D space. This can be an effective method, but limits the field creation to surfaces (of elements) to those that do not overlap in that “one” direction. This can be dealt with by having a group for each surface (of elements). This is discussed herein.
- Another approach is to generate the FEM Field from a domain that is slightly larger than the application region that the field will be used for. This is not always possible for the given model and data, but may be implemented in Patran by slightly scaling-up the original model. A scaling of 1% may be acceptable.
- “Secondary” FEM Field averaging is done if the model the field is being applied to is very small relative to the size of the domain used for creating the FEM Field; as the size of the model approaches the global model tolerance (e.g. 0.005), secondary averaging is done. A possible approach for dealing with this problem is to scale-up the model, even by a factor as large as 10.

# CASE STUDY 6, GENERAL ISSUES FOR CONTINUOUS FEM FIELDS


- Another issue with creating FEM Fields is that this type of field must be created from a contour/fringe or vector plot that is displayed on the screen. For scalar results (e.g. temperature), only contour plots can be created, and elements are needed to create this type of plot.
  - This is a problem for this CASE STUDY as elements were not available with the CFD data.
  - Some CFD software will output elements (generally, triangular elements). If the software being used does not do this, then 2D elements can be created manually in Patran. Sometimes, 3D elements are necessary.

## CASE STUDY 6, PROBLEM USING 1D ELEMENTS

- Attempts have been made to make an FEM Field with 1D elements that connected all the grids. This FEM Field was then applied to a 2D set of elements. The averaging was poor. The only exception was where the CFD node locations very closely or exactly coincided with the structural mesh nodes that the pressure was to be applied to.
- It is not recommended to use FEM Fields created from 1D elements unless the field is applied to 1D elements with the same node locations.

# CASE STUDY 6, MANUALLY CREATE 2D ELEMENTS

- **Because there are no 2D elements to create the FEM Field from, it is necessary to create the elements manually.**
  - Use the form for Elements, and select the nodes that are to be at the corners of the Quad4 elements.



**Finite Elements**

Finite Elements

Action: **Create**

Object: **Element**

Method: **Edit**

Element ID List  
1

Shape: **Quad**

Topology: **Quad4**

Pattern: **Standard**

Prop. Name: - None -  
Prop. Type: - N/A -  
**Select Existing Prop...**  
**Create New Property...**

☒ Use existing midnodes


☒ Auto Execute

Node 1 =   
Node 2 =   
Node 3 =   
Node 4 =

**-Apply-**



## CASE STUDY 6, MANUALLY CREATE 2D ELEMENTS

- Once the 2D elements are created, the model should look like the following. There are no elements on the sides.




# CASE STUDY 6, DISPLAYING TEMPERATURE CONTOUR

- With the 2D elements created, using the imported nodes, the temperature data can be displayed.




# CASE STUDY 6, CREATE FEM FIELD, CONTINUOUS

- Create the FEM Field using the posted temperature fringe.
- Fill out the Fields menu as shown, and go to Options
  - Under Options, check the 2D to 3D interpolation, and pick the direction to project. In this case, it is the Z-direction.
- Ignore (incorrectly) the warning about creating fields from overlapping surfaces, of 2D elements (as seen looking in the Z-direction).




# CASE STUDY 6, CREATE FEM FIELD, CONTINUOUS

- Looking ahead, the consequences of ignoring the surface overlap can be seen.
  - Notice that the pressure distribution for the top and bottom surfaces is similar. This is the first visual clue that something is wrong.




Field, and subsequently, pressure LBC made incorrectly from a temperature contour.




Original Temperature Contour

# CASE STUDY 6, CREATE FEM FIELD, CONTINUOUS


- To make the FEM Field correctly, simply put the top and bottom surfaces (of elements) in separate groups.
  - Post only one of the two groups, then create an FEM Field for it. Repeat this for the other group.
  - The form to the right shows that the FEM field, “pressure\_bottom”, was created, and “pressure\_top” is ready for creation using the top surface of elements.
- Again, make sure that the 2D to 3D interpolation under Options is enabled.



Top Surface





Bottom Surface



# CASE STUDY 6, CREATE FEM FIELD, CONTINUOUS

- Create the pressure LBCs using the two FEM Fields.
  - Loads/BCs: Create/Pressure/Element Uniform
  - Input Data
    - Select one FEM Field (e.g. pressure\_top)
  - Application Region
    - Select the corresponding surface (e.g. top surface (of elements))



# EXERCISES

- Perform Workshop 19 “Global/Local Modeling Using FEM Fields” in your exercise workbook.



# FIELDS, MATERIAL PROPERTY/TABULAR INPUT

- This type of field is used to create varying material properties using tabular input.
- The independent variable(s) can be chosen to appropriately describe the material behavior.
  - Any combination of the three variables Temperature, Strain, or Strain Rate can be used for a field. If the variable Time or Frequency is used, only one of them can be used, and none of the other three variables can be used.

**Fields**

Fields

Action:

Object:

Method:

Existing Fields

Field Name

Table Definition

Active Independent Variables

☒ Temperature (T)

☒ Strain (e)

☒ Strain Rate (er)

☐ Time (t)


☐ Frequency (f)

☐ Magnetic Induction (B)

☐ Magnetic Field Intensity (H)

# FIELDS, MATERIAL PROPERTY/TABULAR INPUT

- The number of variables selected determines whether a one-, two-, or three-dimensional table for input will be displayed.



3D Material Scalar Table Data


Input Data ☐ Auto Highlight Import/Export...

Data

	e-1	e-2
T-1		
T-2		
T-3		
T-4		
T-5		
T-6		
T-7		

Layer: 1 er

OK Undo



Fields

Action: Create

Object: Material Property

Method: Tabular Input

Existing Fields

Field Name

Table Definition

Active Independent Variables




- ☒ Temperature (T)
- ☒ Strain (e)
- ☒ Strain Rate (er)
- ☐ Time (t)
- ☐ Frequency (f)
- ☐ Magnetic Induction (B)
- ☐ Magnetic Field Intensity (H)

Input Data ...

[Options...]



# FIELDS, MATERIAL PROPERTY/TABULAR INPUT, OPTIONS

- The top portion of the Tabular Input, [Options] form controls how many data points can be input for each variable (e.g. Temperature).
- **Extrapolation Option** includes the following choices:
  - Use Closest Table Value
  - Linear Extrapolation
  - Set Value to Zero
- **Incomplete Data Action** allows the selection of how not having adequate data will be dealt with






# FIELDS, MATERIAL PROPERTY/GENERAL

- **Material Properties/General** allows the cross reference of any material property to any other property or a user defined equation.
  - With **Function Term Type** set to **P3 Functions**, an original function will be created.
  - With **Function Term Type** set to **Independent Variables**, predefined functions (e.g. er) can be picked and included in the equation.




# FIELDS, MATERIAL PROPERTY/MODEL VARIABLE

- Material Property/Model Variable is intended for creating fields from user defined variables.
- To create, modify, show, or delete the variables for Material Property fields, select Create/Variable
- The variables can also be accessed under Tools: Model Variables from the Patran main menu.




# FIELDS MODEL VARIABLE

- **Model variables are single value parameters (constants).**
- **The value can be specified either by specifying a numerical value or extracting one from existing Property, Beam Dimension or Material.**
  - If the value is extracted, the original numerical value is replaced with a variable name.
  - Once the variable is created, it can be changed or checked under Modify/Variable or Show/Variable.
- **Once variables are used in LBCs, materials, or element properties, they can be modified; they can be used in parametric studies.**



# FIELDS MODEL VARIABLE


- **Create/Variable/Value** has an additional option to subsequently create a Field.
  - If **Create Referencing Field** is checked, then, a Field that references the variable will be created with the same name as the variable. The Field is pickable from Load/BCs, Properties and Properties/Beam Library.
    - For the field to appear in Material, the variable has been created under Variable/Material
  - If the **Create Referencing Field** is un-checked, then a field will not be created automatically.
    - A Field created with that variable can still be used in any part of Patran where it is appropriate (e.g. Loads/BCs).





# CASE STUDY 7, MATERIAL PROPERTY FIELD

- Create a single field that describes an Aluminum alloy over a temperature and strain domain.
- Use the table data provided



**Stress vs.  
Temperature and Strain**

		Strain	
Temp (F)		0.00388	0.2
70	0	40,000	60,000
120	0	36,782	54,882
170	0	32,010	47,810

# CASE STUDY 7, MATERIAL PROPERTY FIELD

- To create the field, select Temperature and Strain for Active Independent Variables.
- Enter the data in the Input Data form
  - The first column are the temperatures (rows 1,2,3).
  - The first row contains the strains (columns 1,2,3).
  - The table entries are the stresses for the corresponding temperatures and strains.

2D Material Scalar Table Data

Input Data ☐ Auto Highlight 

Data

		e-1	e-2
		0.000000E+000	3.880000E-003
T-1	7.000000E+001	0.000000E+000	4.000000E+004
T-2	1.200000E+002	0.000000E+000	3.678200E+004
T-3	1.700000E+002	0.000000E+000	3.201000E+004
T-4			
T-5			
T-6			
T-7			
T-8			

OK Undo

2D Material Scalar Table Data

Input Data ☐ Auto Highlight 

Data

		e-1	e-2	e-3
		0.000000E+000	3.880000E-003	2.000000E-001
T-1	0.000000E+000	4.000000E+004	6.000000E+004	
T-2	0.000000E+000	3.678200E+004	5.488200E+004	
T-3	0.000000E+000	3.201000E+004	4.781000E+004	
T-4				
T-5				
T-6				
T-7				
T-8				

OK Undo

Fields

Action:

Object:

Method:

Existing Fields

Field Name:

Table Definition

Active Independent Variables

☒ Temperature (T)

☒ Strain (e)

☐ Strain Rate (er)

☐ Time (t)


☐ Frequency (f)

☐ Magnetic Induction (B)

☐ Magnetic Field Intensity (H)

# CASE STUDY 7, MATERIAL PROPERTY FIELD

- In [Options] the Extrapolation Option chosen does not affect the field evaluation for the Nastran preference. Nastran will do a linear interpolation between adjacent (strain, stress) points.
- The number of rows and columns can be specified, but for this case, 30 is sufficient.



# CASE STUDY 7, CREATE MATERIAL USING FIELD

- In Materials, Input Properties there are two steps for making the nonlinear material.
  - With Constitutive Model set to **Linear Elastic**, the linear properties can be specified.
- Although not always required, many times the elastic modulus for the linear elastic constitutive model is set to match the first elastic data used to create the stress/strain field.
  - For Nastran, consult the Quick Guide for more

**Input Options**

Constitutive Model: **Linear Elastic**

Elastic Modulus = 10.3e6

Poisson Ratio = 0.33

Shear Modulus = 1.28e6

Density = 0.101

Thermal Expansion Coeff = 1.28e-5

Structural Damping Coeff = 0

Reference Temperature =

Temperature Dep/Model Variable Fields:

Current Constitutive Models:

OK Clear Cancel

**Materials**

Materials

Action: **Create**

Object: **Isotropic**

Method: **Manual Input**

Existing Materials

Filter

Material Name: **Aluminum**

Description: **Date: 10-Aug-31 Time: 10:04:12**


Input Properties ...

Change Material Status ...


Apply

# CASE STUDY 7, CREATE MATERIAL USING FIELD

- Set the **Constitutive Model** to **Nonlinear Elastic**, and select the previously created field from the **Strain and Strain/TEMP Dependent Fields**, **Material\_Field** for the nonlinear properties of Aluminum.



The **Input Options** dialog box is shown. It has a title bar with standard window controls. The **Constitutive Model** is set to **Nonlinear Elastic**. Below this, there is a table with two columns: **Property Name** and **Value**. The first row shows **Stress/Strain Curve =** with the value **Material\_Field**. Under the **Strain and Strain/Temp Dependent Fields** section, **Material\_Field** is selected in a list box. The **Current Constitutive Models** section is empty. At the bottom are **OK**, **Clear**, and **Cancel** buttons.



The **Materials** dialog box is shown. It has a title bar with standard window controls. The **Action** is set to **Create**, the **Object** is set to **Isotropic**, and the **Method** is set to **Manual Input**. Below these are the **Existing Materials** list, a **Filter** button, and a text field. The **Material Name** is set to **Aluminum**. The **Description** section shows **Date: 10-Aug-31** and **Time: 10:04:12**. At the bottom are **Input Properties ...**, **Change Material Status ...**, and **Apply** buttons.



# FIELDS, NON SPATIAL/TABULAR INPUT




- **Non Spatial, Real fields** are used to create time or frequency dependent fields for transient or frequency response analysis.
- **Non Spatial, Complex fields** are used primarily for frequency response analysis.

The screenshot shows the 'Fields' dialog box with the following settings:

- Action:** Create
- Object:** Non Spatial
- Method:** Tabular Input
- Existing Fields:** (Empty list)
- Field Name:** (Empty text box)
- Scalar Field Type:**
  - ☒ Real
  - ☐ Complex
- Table Definition:**
  - Active Independent Variables (Limit = 3):**
    - ☒ Time (t)
    - ☐ Frequency (f)
    - ☐ Temperature (T)
    - ☐ Displacement (u)
    - ☐ Velocity (v)
    - ☐ User-Defined (UD)
- Buttons:** Input Data ..., [Options...], -Apply-

# FIELDS, NON SPATIAL/TABULAR INPUT

- Create non-spatial field
  - Real
  - Time
  - Map Function to Table
  - PCL Expression  $f(\text{time})$



# FIELDS, NON SPATIAL/TABULAR INPUT

- Edit the columns to include two additional points (Time, Value)


Non Spatial Scalar Table Data

Input Data: 0 ☐ Auto Highlight

Data

	t	Value
t-23	8.1481469E-001	7.5187502E+000
t-24	8.5185170E-001	7.4219141E+000
t-25	8.8888872E-001	7.3263254E+000
t-26	9.2592573E-001	7.2319674E+000
t-27	9.6296275E-001	7.1388245E+000
t-28	9.9999976E-001	7.0468812E+000
t-29	1.1000000E+000	0.0000000E+000
t-30	3.0000000E+000	0.0000000E+000

# FIELDS, NON SPATIAL/TABULAR INPUT



# FIELDS, NON SPATIAL/TABULAR INPUT

