

Настройка BIOS

Лекцию подготовил
преподаватель
Тукубаев Андрей Серикович

Конспект лекции vk.com/as_os

686
AMIBIOS®
©1999
YH79
6 4 6 6

128

10

64

001




GIGABYTE®

002

MSRock

Z68 Professional Gen 3

003



005



006



007



008



 Award Modular BIOS v6.00PG
Copyright (C) 1984-2011, Award Software, Inc.

Z68X-UD3P-B3 F4

Main Processor : Intel(R) Core(TM) i5-2500K CPU 4.70GHz(100x47)
<CPUID:000206A7 Patch ID:00000014>
Memory Testing : 4080MB OK

Memory Frequency 1600MHz

:BIOS Setup <F9>:XpressRecovery2 <F12>:Boot Menu <End>:Qflash
05/02/2011-Z68-7A89VG0UC-00

009

X7

F8 F9 F10 F11 F12

Print Screen SysRq Scroll Lock Pause Break

Mode ON/OFF G800V X7 WINNER'S CHOICE

(9) 0 - _ + = ← Backspace

G14 G15 G16

Num Lock / * -

O P { [}] Enter ↵

Insert Home Page Up

7 Home 8 ↑ 9 PgUp +

K L ; ' : \ /

Delete End Page Down

4 ← 5 6 →

< , > . ? / Shift

Red arrow key

1 End 2 ↓ 3 PgDn Enter

13 Alt Windows logo Alt key Ctrl

Red arrow keys

0 Ins Del

010

 Award Modular BIOS v6.00PG
Copyright (C) 1984-2011, Award Software, Inc.

Z68X-UD3P-B3 F4

Main Processor : Intel(R) Core(TM) i5-2500K CPU 4.70GHz(100x47)
<CPUID:000206A7 Patch ID:00000014>
Memory Testing : 4080MB OK

Memory Frequency 1600MHz

:BIOS Setup <F9>:XpressRecovery2 <F12>:Boot Menu <End>:Qflash
05/02/2011-Z68-7A89VG0UC-00

011



012

- ▶ Standard CMOS Features
- ▶ Advanced BIOS Features
- ▶ Advanced Chipset Features
- ▶ Integrated Peripherals
- ▶ Power Management Features
- ▶ PNP/PCI Configurations
- ▶ PC Health Status

▶ Cell_Menu

- Load Fail-Safe Defaults
- Load Optimized Defaults
- BIOS Setting Password
- Save & Exit Setup
- Exit Without Saving

↑↓←→:Move Enter:Select +/-/:Value F10:Save ESC:Exit F1:General Help
F6:Load Optimized Defaults F7 :Load Fail-Safe Defaults

Set Frequency, Spread Spectrum Function ...

Standard CMOS Features	[Setup Help]
System Time 16:10:28 System Date Mar 14 2003 Fri	Time is 24 hour format
Current Language English	Hour: 00 - 23 Minute: 00 - 59 Second: 00 - 59
<ul style="list-style-type: none"> ▶ Primary IDE Master ▶ Primary IDE Slave ▶ Secondary IDE Master ▶ Secondary IDE Slave 	(1:30AM = 01:30:00, 1:30PM = 13:30:00)
<ul style="list-style-type: none"> ▶ Third IDE Master Not Installed ▶ Third IDE Slave Not Installed ▶ Fourth IDE Master Not Installed ▶ Fourth IDE Slave Not Installed 	
Floppy Drive A 1.44 MB 3.5 Floppy Drive B Not Installed	

probios.ru

014

Advanced BIOS Features

[Setup Help]

Quick Boot	Enabled
▶ Boot Device Select ...	
Full Screen LOGO Show	Disabled
S.M.A.R.T. for Hard Disks	Disabled
BootUp Num-Lock	On
Floppy Drive Swap	Disabled
Floppy Drive Seek	Disabled
Password Check	Setup
Save current ROM to HDD	No
Boot To OS/2	No
Hyper Threading Function	Enabled
MPS Revision	1.4
APIC ACPI SCI IRQ	Disabled
CPU L1 & L2 Cache	Enabled
System BIOS Cacheable	Disabled
C000,32k Shadow	Cached


 probios.ru

 F1:Help ↑↓:Select Item
 Esc:Previous Menu

 +/-:Change Values
 Enter:Select ▶Sub-Menu

 F9:Setup Defaults
 F10:Save & Exit

Advanced Chipset Features

[Setup Help]

▶ DRAM Timing Setting ...

AGP Aperture Size 64MB

Internal Graphics Mode Select 8MB

F1:Help

Esc:Previous Menu

↑↓:Select Item

+/-:Change Values

Enter:Select ▶Sub-Menu

F9:Setup Defaults

F10:Save & Exit

Power Management Features

[Setup Help]

ACPI Standby State	S1/POS
Re-Call VGA BIOS at S3 Resuming	Enabled
Power Management/APM	Enabled
Suspend Time Out (Minute)	Disabled
Power Button Function	On/Off
Restore on AC/Power Loss	Last State
▶ Set Monitor Events ...	
▶ Set Wake Up Events ...	


 probios.ru

 F1:Help ↑↓:Select Item
 Esc:Previous Menu

 +/-:Change Values
 Enter:Select ▶Sub-Menu

 F9:Setup Defaults
 F10:Save & Exit

PNP/PCI Configurations

[Setup Help]

Clear NURAM	No
PCI Latency Timer (PCI Clocks)	32
Init. Graphics Adapter Priority	AGP/Int-VGA
PCI IDE BusMaster	Disabled
PCI Slot1 IRQ Priority	Auto
PCI Slot2/5 IRQ Priority	Auto
PCI Slot3 IRQ Priority	Auto
PCI Slot4 IRQ Priority	Auto
▶ Set IRQs to PCI or ISA	
▶ Set DMAs to PnP or ISA	

probios.ru

F1:Help ↑↓:Select Item
Esc:Previous Menu+/-:Change Values
Enter:Select ▶Sub-MenuF9:Setup Defaults
F10:Save & Exit

Integrated Peripherals

[Setup Help]

USB Controller	Enabled
USB Device Legacy Support	Disabled
▶ On-Chip IDE Configuration	
C.S.A. Gigabit Ethernet	Auto
OnBoard 1394	Enabled
OnBoard Promise IDE	As S-ATA
AC'97 Audio	Auto
▶ Set Super I/O	

probios.ru

F1:Help ↑↓:Select Item
Esc:Previous Menu+/-:Change Values
Enter:Select ▶Sub-MenuF9:Setup Defaults
F10:Save & Exit

PC Health Status

[Setup Help]

Chassis Intrusion	Disabled
CPU Temperature	80°C/176°F
System Temperature	39°C/102°F
CPU Fan Speed	4328RPM
MB Fan Speed	2516RPM
Vcore	1.748V
3.3V	3.310V
+ 5.0V	5.143V
+12.0V	11.857V
-12.0V	12.125V
- 5.0V	4.986V
Battery	3.254V
+5V SB	4.892V

probios.ru

F1:Help ↑↓:Select Item
Esc:Previous Menu+/-:Change Values
Enter:Select ▶Sub-MenuF9:Setup Defaults
F10:Save & Exit

Frequency/Voltage Control

[Setup Help]

CPU Ratio Selection	8.0x
DRAM Frequency	Auto
Spread Spectrum	Enabled
Adjust CPU Bus Clock(MHz)	133
DDR Clock(MHz)	133
Adjust AGP/PCI Clock(MHz)	66.66/33.33
CPU Vcore Adjust	No
CPU Vcore	1.750V
DDR Power Voltage	2.50V
AGP Power Voltage	1.50V


 probios.ru

 F1:Help ↑↓:Select Item
 Esc:Previous Menu

 +/-:Change Values
 Enter:Select ▶Sub-Menu

 F9:Setup Defaults
 F10:Save & Exit