
FEATURES OF DESIGN OF AIRBORNE RADIO ELECTRONIC FACILITIES IN THE ALTIUM DESIGNER ENVIRONMENT


STRUCTURAL MODULES OF ALTIUM DESIGNER


- development of electronic circuits;
- design of printed circuit boards;
- development of embedded software;
- mixed analog-digital simulation;
- signal integrity analysis;
- technological preparation of manufacturing;
- design of systems based on PLIC and their debugging with the use of the Altium NanoBoard breadboard.

THE ALTIUM DESIGNER WINDOW CONTAINS THE FOLLOWING BASIC ELEMENTS:

- System menu and toolbars, content and composition of which varies depending on the type of active document;
- 2. Auxiliary panels, which have multiple display modes;
- 3. Workspace;
- Integrated support for Altium Designer, which provides access to the built-in help pages and resources located in the Internet (Altium Wiki).









POSSIBLE TYPES OF THE CONNECTED DOCUMENT:


- 1. Schematic a schematic document;
- 2. PCB a file of a printed circuit board;
- 3. Schematic Library a library of schematic symbols;
- 4. PCB Library a library of topological sites;
- 5. CAM Document a document of a CAM-program;
- 6. Output Job File a file of output data for processing;
- 7. Database Link File a file pointer to the link to the database;
- 8. Text Document a text document;
- 9. Other other documents.





THE COMPONENT PROPERTIES WINDOW

- Properties the main component properties (Designator – the positional notation, Comment – the component name);
- Library Link the link to the library;
- Graphical the information about the component graphic display;
- Parameters the component attributes (hence the information about the component will be used to form the text part of design);
- Models the component models (sites);
- Edit Pins the table of component pins.









THE COMPILATION PROCESS CONSISTS OF THE FOLLOWING STAGES:

- Setting project options;
- Starting compilation;
- Search and fix errors.

THE PREFERENCES IN THE PRINTED BOARDS EDITOR

- Local preferences of the current document.
- Global preferences of the editor.
- Display preferences.